




# Installation and operation manual

## VRV IV system air conditioner



**RXMLQ8T7Y1B\***  
**RXYLQ10T7Y1B\***  
**RXYLQ12T7Y1B\***  
**RXYLQ14T7Y1B\***

Installation and operation manual  
VRV IV system air conditioner

**English**

## Table of contents

<b>1</b>	<b>About the documentation</b>	<b>3</b>
1.1	About this document.....	3
<b>2</b>	<b>Specific installer safety instructions</b>	<b>3</b>
<b>For the user</b>		
<b>3</b>	<b>User safety instructions</b>	<b>4</b>
3.1	General.....	4
3.2	Instructions for safe operation .....	5
<b>4</b>	<b>About the system</b>	<b>6</b>
4.1	System layout.....	6
<b>5</b>	<b>User interface</b>	<b>6</b>
<b>6</b>	<b>Operation</b>	<b>7</b>
6.1	Operation range.....	7
6.2	Operating the system .....	7
6.2.1	About operating the system .....	7
6.2.2	About cooling, heating, fan only, and automatic operation.....	7
6.2.3	About the heating operation.....	7
6.2.4	To operate the system (WITHOUT cool/heat changeover remote control switch).....	7
6.2.5	To operate the system (WITH cool/heat changeover remote control switch).....	7
6.3	Using the dry program.....	8
6.3.1	About the dry program .....	8
6.3.2	To use the dry program (WITHOUT cool/heat changeover remote control switch).....	8
6.3.3	To use the dry program (WITH cool/heat changeover remote control switch).....	8
6.4	Adjusting the air flow direction.....	8
6.4.1	About the air flow flap .....	8
6.5	Setting the master user interface.....	8
6.5.1	About setting the master user interface .....	8
<b>7</b>	<b>Maintenance and service</b>	<b>9</b>
7.1	About the refrigerant.....	9
7.2	After-sales service and warranty .....	9
7.2.1	Warranty period .....	9
7.2.2	Recommended maintenance and inspection.....	9
<b>8</b>	<b>Troubleshooting</b>	<b>9</b>
8.1	Error codes: Overview .....	10
8.2	Symptoms that are NOT system malfunctions .....	11
8.2.1	Symptom: The system does not operate .....	11
8.2.2	Symptom: Cool/Heat cannot be changed over .....	11
8.2.3	Symptom: Fan operation is possible, but cooling and heating do not work.....	11
8.2.4	Symptom: The fan speed does not correspond to the setting .....	11
8.2.5	Symptom: The fan direction does not correspond to the setting .....	11
8.2.6	Symptom: White mist comes out of a unit (Indoor unit) .....	11
8.2.7	Symptom: White mist comes out of a unit (Indoor unit, outdoor unit).....	11
8.2.8	Symptom: The user interface reads "U4" or "U5" and stops, but then restarts after a few minutes .....	11
8.2.9	Symptom: Noise of air conditioners (Indoor unit).....	11
8.2.10	Symptom: Noise of air conditioners (Indoor unit, outdoor unit).....	12
8.2.11	Symptom: Noise of air conditioners (Outdoor unit).....	12
8.2.12	Symptom: Dust comes out of the unit.....	12
8.2.13	Symptom: The units can give off odours.....	12
8.2.14	Symptom: The outdoor unit fan does not spin .....	12


8.2.15	Symptom: The display shows "88".....	12
8.2.16	Symptom: The compressor in the outdoor unit does not stop after a short heating operation .....	12
8.2.17	Symptom: The inside of an outdoor unit is warm even when the unit has stopped .....	12
8.2.18	Symptom: Hot air can be felt when the indoor unit is stopped .....	12

## 9 Relocation 12

## 10 Disposal 12

## For the installer 12

## 11 About the box 12

11.1	About  .....	12
11.2	To remove the accessories from the outdoor unit .....	12
11.3	Accessory pipes: Diameters .....	13
11.4	To remove the transportation stay.....	13

## 12 About the units and options 13

12.1	About the outdoor unit .....	13
12.2	System layout.....	13

## 13 Unit installation 14

13.1	Preparing the installation site .....	14
13.1.1	Installation site requirements of the outdoor unit .....	14
13.1.2	Additional installation site requirements of the outdoor unit in cold climates .....	14
13.2	Opening the unit .....	14
13.2.1	To open the outdoor unit.....	14
13.2.2	To open the switch box of the outdoor unit .....	14
13.3	Mounting the outdoor unit.....	14
13.3.1	To provide the installation structure .....	14

## 14 Piping installation 15

14.1	Preparing refrigerant piping .....	15
14.1.1	Refrigerant piping requirements.....	15
14.1.2	To select the piping size .....	15
14.1.3	To select refrigerant branch kits.....	17
14.1.4	Multiple outdoor units: Possible layouts.....	17
14.2	Connecting the refrigerant piping .....	18
14.2.1	To route the refrigerant piping.....	18
14.2.2	To connect the refrigerant piping to the outdoor unit ..	18
14.2.3	To connect the multi connection piping kit.....	18
14.2.4	To connect the refrigerant branching kit .....	18
14.2.5	To protect against contamination.....	19
14.2.6	Using the stop valve and service port.....	19
14.2.7	To remove the spun pipes .....	19
14.3	Checking the refrigerant piping.....	20
14.3.1	About checking the refrigerant piping .....	20
14.3.2	Checking refrigerant piping: General guidelines .....	20
14.3.3	Checking refrigerant piping: Setup.....	21
14.3.4	To perform a leak test .....	21
14.3.5	To perform vacuum drying.....	21
14.3.6	To insulate the refrigerant piping .....	21
14.4	Charging refrigerant.....	22
14.4.1	Precautions when charging refrigerant .....	22
14.4.2	About charging refrigerant .....	22
14.4.3	To determine the additional refrigerant amount.....	22
14.4.4	To charge refrigerant: Flow chart.....	22
14.4.5	To charge refrigerant .....	24
14.4.6	Step 6: To manually charge refrigerant.....	24
14.4.7	Checks after charging refrigerant.....	24
14.4.8	To fix the fluorinated greenhouse gases label .....	24

## 15 Electrical installation 25

15.1	About electrical compliance.....	25
15.2	Safety device requirements .....	25
15.3	Field wiring: Overview .....	25

15.4	To route and fix the interconnection wiring.....	26
15.5	To connect the interconnection wiring.....	26
15.6	To finish the interconnection wiring.....	27
15.7	To route and fix the power supply.....	27
15.8	To connect the power supply.....	27
15.9	To check the insulation resistance of the compressor.....	27
<b>16</b>	<b>Configuration</b>	<b>27</b>
16.1	Making field settings.....	28
16.1.1	About making field settings.....	28
16.1.2	Field setting components.....	28
16.1.3	To access the field setting components.....	28
16.1.4	To access mode 1 or 2.....	29
16.1.5	To use mode 1.....	29
16.1.6	To use mode 2.....	29
16.1.7	Mode 1: monitoring settings.....	29
16.1.8	Mode 2: field settings.....	30
16.1.9	To connect the PC configurator to the outdoor unit....	31
<b>17</b>	<b>Commissioning</b>	<b>31</b>
17.1	Precautions when commissioning.....	31
17.2	Checklist before commissioning.....	31
17.3	About the system test run.....	32
17.4	To perform a test run.....	32
17.5	Correcting after abnormal completion of the test run.....	32
<b>18</b>	<b>Hand-over to the user</b>	<b>32</b>
<b>19</b>	<b>Troubleshooting</b>	<b>33</b>
19.1	Solving problems based on error codes.....	33
19.2	Error codes: Overview.....	33
<b>20</b>	<b>Technical data</b>	<b>36</b>
20.1	Service space: Outdoor unit.....	36
20.2	Piping diagram: Outdoor unit.....	37
20.3	Wiring diagram: Outdoor unit.....	37
<b>21</b>	<b>Disposal</b>	<b>38</b>

## 1 About the documentation

### 1.1 About this document

#### Target audience

Authorised installers + end users



#### INFORMATION

This appliance is intended to be used by expert or trained users in shops, in light industry and on farms, or for commercial use by lay persons.

#### Documentation set

This document is part of a documentation set. The complete set consists of:

- **General safety precautions:**
  - Safety instructions that you must read before installing
  - Format: paper (in the box of the outdoor unit)
- **Outdoor unit installation and operation manual:**
  - Installation and operation instructions
  - Format: paper (in the box of the outdoor unit)
- **Installer and user reference guide:**
  - Preparation of the installation, reference data,...
  - Detailed step-by-step instructions and background information for basic and advanced usage
  - Format: Digital files on <https://www.daikin.eu>. Use the search function 🔍 to find your model.

The latest revision of the supplied documentation is published on the regional Daikin website and is available via your dealer.

The original instructions are written in English. All other languages are translations of the original instructions.

#### Technical engineering data

- A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible).
- The **full set** of the latest technical data is available on the Daikin Business Portal (authentication required).

## 2 Specific installer safety instructions

Always observe the following safety instructions and regulations.



#### WARNING

Tear apart and throw away plastic packaging bags so that nobody, especially children, can play with them. **Possible consequence:** suffocation.



#### CAUTION

Appliance NOT accessible to the general public, install it in a secured area, protected from easy access.

This unit, both indoor and outdoor, is suitable for installation in a commercial and light industrial environment.



#### CAUTION

Excessive refrigerant concentrations in a closed room can lead to oxygen deficiency.



#### DANGER: RISK OF ELECTROCUTION

Do NOT leave the unit unattended when the service cover is removed.



#### DANGER: RISK OF BURNING/SCALDING



#### DANGER: RISK OF ELECTROCUTION



#### WARNING

Take sufficient precautions in case of refrigerant leakage. If refrigerant gas leaks, ventilate the area immediately. Possible risks:

- Excessive refrigerant concentrations in a closed room can lead to oxygen deficiency.
- Toxic gas might be produced if refrigerant gas comes into contact with fire.



#### WARNING

ALWAYS recover the refrigerant. Do NOT release them directly into the environment. Use a vacuum pump to evacuate the installation.



#### WARNING

During tests, NEVER pressurise the product with a pressure higher than the maximum allowable pressure (as indicated on the nameplate of the unit).



#### CAUTION

Do NOT vent gases into the atmosphere.



#### WARNING

Any gas or oil remaining inside the stop valve may blow off the spun piping.

If these instructions are NOT followed correctly it may result in property damage or personal injury, which may be serious depending on the circumstances.

### 3 User safety instructions

#### WARNING



NEVER remove the spun piping by brazing.

Any gas or oil remaining inside the stop valve may blow off the spun piping.

#### WARNING

- ONLY use R410A as refrigerant. Other substances may cause explosions and accidents.
- R410A contains fluorinated greenhouse gases. Its global warming potential (GWP) value is 2087.5. Do NOT vent these gases into the atmosphere.
- When charging refrigerant, ALWAYS use protective gloves and safety glasses.

#### CAUTION

Do NOT push or place redundant cable length into the unit.

#### WARNING

- If the power supply has a missing or wrong N-phase, equipment might break down.
- Establish proper earthing. Do NOT earth the unit to a utility pipe, surge absorber, or telephone earth. Incomplete earthing may cause electrical shocks.
- Install the required fuses or circuit breakers.
- Secure the electrical wiring with cable ties so that the cables do NOT come in contact with sharp edges or piping, particularly on the high-pressure side.
- Do NOT use taped wires, extension cords, or connections from a star system. They can cause overheating, electrical shocks or fire.
- Do NOT install a phase advancing capacitor, because this unit is equipped with an inverter. A phase advancing capacitor will reduce performance and may cause accidents.

#### WARNING

- All wiring MUST be performed by an authorised electrician and MUST comply with the national wiring regulation.
- Make electrical connections to the fixed wiring.
- All components procured on-site and all electrical construction MUST comply with the applicable legislation.

#### WARNING

ALWAYS use multicore cable for power supply cables.

#### CAUTION

- When connecting the power supply: connect the earth cable first, before making the current-carrying connections.
- When disconnecting the power supply: disconnect the current-carrying cables first, before separating the earth connection.
- The length of the conductors between the power supply stress relief and the terminal block itself MUST be as such that the current-carrying wires are tightened before the earth wire is in case the power supply is pulled loose from the stress relief.

#### CAUTION

**Do NOT perform the test operation while working on the indoor unit(s).**

When performing the test operation, NOT ONLY the outdoor unit, but the connected indoor unit will operate as well. Working on an indoor unit while performing a test operation is dangerous.

#### CAUTION

Do NOT insert fingers, rods or other objects into the air inlet or outlet. Do NOT remove the fan guard. When the fan is rotating at high speed, it will cause injury.

## For the user

### 3 User safety instructions

Always observe the following safety instructions and regulations.

#### 3.1 General

#### WARNING

If you are NOT sure how to operate the unit, contact your installer.

#### WARNING

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction

concerning use of the appliance in a safe way and understand the hazards involved.

Children SHALL NOT play with the appliance.

Cleaning and user maintenance SHALL NOT be made by children without supervision.

#### WARNING

To prevent electrical shocks or fire:

- Do NOT rinse the unit.
- Do NOT operate the unit with wet hands.
- Do NOT place any objects containing water on the unit.

### CAUTION

- Do NOT place any objects or equipment on top of the unit.
- Do NOT sit, climb or stand on the unit.

- Units are marked with the following symbol:



This means that electrical and electronic products may NOT be mixed with unsorted household waste. Do NOT try to dismantle the system yourself: dismantling the system, treatment of the refrigerant, of oil and of other parts MUST be done by an authorised installer and MUST comply with applicable legislation.

Units MUST be treated at a specialised treatment facility for reuse, recycling and recovery. By ensuring this product is disposed of correctly, you will help to prevent potential negative consequences for the environment and human health. For more information, contact your installer or local authority.

- Batteries are marked with the following symbol:



This means that the batteries may NOT be mixed with unsorted household waste. If a chemical symbol is printed beneath the symbol, this chemical symbol means that the battery contains a heavy metal above a certain concentration.

Possible chemical symbols are: Pb: lead (>0.004%).

Waste batteries MUST be treated at a specialised treatment facility for reuse. By ensuring waste batteries are disposed of correctly, you will help to prevent potential negative consequences for the environment and human health.

## 3.2 Instructions for safe operation

### CAUTION

- NEVER touch the internal parts of the controller.
- Do NOT remove the front panel. Some parts inside are dangerous to touch and appliance problems may happen. For checking and adjusting the internal parts, contact your dealer.

### CAUTION

Do NOT operate the system when using a room fumigation-type insecticide. Chemicals could collect in the unit, and endanger the health of people who are hypersensitive to chemicals.

### CAUTION

It is unhealthy to expose your body to the air flow for a long time.

### CAUTION

To avoid oxygen deficiency, ventilate the room sufficiently if equipment with burner is used together with the system.

### WARNING

This unit contains electrical and hot parts.

### WARNING

Before operating the unit, be sure the installation has been carried out correctly by an installer.

### WARNING

NEVER touch the air outlet or the horizontal blades while the swing flap is in operation. Fingers may become caught or the unit may break down.

### CAUTION

Do NOT insert fingers, rods or other objects into the air inlet or outlet. Do NOT remove the fan guard. When the fan is rotating at high speed, it will cause injury.

### CAUTION: Pay attention to the fan!

It is dangerous to inspect the unit while the fan is running.

Make sure to turn OFF the main switch before executing any maintenance task.

### CAUTION

After a long use, check the unit stand and fitting for damage. If damaged, the unit may fall and result in injury.

### WARNING

NEVER replace a fuse with a fuse of a wrong ampere ratings or other wires when a fuse blows out. Use of wire or copper wire may cause the unit to break down or cause a fire.

### WARNING

- Do NOT modify, disassemble, remove, reinstall or repair the unit yourself as incorrect dismantling or installation may cause an electrical shock or fire. Contact your dealer.
- In case of accidental refrigerant leaks, make sure there are no naked flames. The refrigerant itself is entirely safe, non-toxic and non-combustible, but it will generate toxic gas when it accidentally leaks into a room where combustion air from fan heaters, gas cookers, etc. is present. ALWAYS have qualified service personnel confirm that the point of leakage has been repaired or corrected before resuming operation.

### WARNING

**Stop operation and shut OFF the power if anything unusual occurs (burning smells etc.).**

Leaving the unit running under such circumstances may cause breakage, electrical shock or fire. Contact your dealer.

### WARNING

- The refrigerant in the system is safe and normally does NOT leak. If the refrigerant leaks in the room, contact with a fire of a burner, a heater or a cooker may result in a harmful gas.
- Turn OFF any combustible heating devices, ventilate the room and contact the dealer where you purchased the unit.
- Do NOT use the system until a service person confirms that the portion where the refrigerant leaks is repaired.

### CAUTION

NEVER expose little children, plants or animals directly to the airflow.

### CAUTION

Do NOT touch the heat exchanger fins. These fins are sharp and could result in cutting injuries.

## 4 About the system

The indoor unit part of VRV IV heat pump system can be used for heating/cooling applications. The type of indoor unit which can be used depends on the outdoor units series.

### WARNING

- Do NOT modify, disassemble, remove, reinstall or repair the unit yourself as incorrect dismantling or installation may cause an electrical shock or fire. Contact your dealer.
- In case of accidental refrigerant leaks, make sure there are no naked flames. The refrigerant itself is entirely safe, non-toxic and non-combustible, but it will generate toxic gas when it accidentally leaks into a room where combustion air from fan heaters, gas cookers, etc. is present. ALWAYS have qualified service personnel confirm that the point of leakage has been repaired or corrected before resuming operation.

### NOTICE

Do NOT use the system for other purposes. In order to avoid any quality deterioration, do NOT use the unit for cooling precision instruments, food, plants, animals, or works of art.

### NOTICE

For future modifications or expansions of your system:

A full overview of allowable combinations (for future system extensions) is available in technical engineering data and should be consulted. Contact your installer to receive more information and professional advice.

## 4.1 System layout

Depending on the type of outdoor unit which is chosen, some functionality will or will not exist. It will be indicated throughout this operation manual when certain features have exclusive model rights or not.

### INFORMATION

The following figure is an example and may NOT completely match your system layout.

## 5 User interface

### CAUTION

- NEVER touch the internal parts of the controller.
- Do NOT remove the front panel. Some parts inside are dangerous to touch and appliance problems may happen. For checking and adjusting the internal parts, contact your dealer.

This operation manual offers a non-exhaustive overview of the main functions of the system.

Detailed information on required actions to achieve certain functions can be found in the dedicated installation and operation manual of the indoor unit.

Refer to the operation manual of the installed user interface.



## 6 Operation

### 6.1 Operation range

Use the system in the following temperature and humidity ranges for safe and effective operation.

	Cooling	Heating
Outdoor temperature	–5~43°C DB	–20~21°C DB –25~15.5°C WB
Indoor temperature	21~32°C DB 14~25°C WB	15~27°C DB
Indoor humidity	≤80% <sup>(a)</sup>	

<sup>(a)</sup> To avoid condensation and water dripping out of the unit. If the temperature or the humidity is beyond these conditions, safety devices may be put in action and the air conditioner may not operate.

Above operation range is only valid in case direct expansion indoor units are connected to the VRV IV system.

Special operation ranges are valid in case of using Hydrobox units or AHU. They can be found in the installation/operation manual of the dedicated unit. Latest information can be found in the technical engineering data.

### 6.2 Operating the system

#### 6.2.1 About operating the system

- Operation procedure varies according to the combination of outdoor unit and user interface.
- To protect the unit, turn on the main power switch 6 hours before operation.
- If the main power supply is turned off during operation, operation will restart automatically after the power turns back on again.

#### 6.2.2 About cooling, heating, fan only, and automatic operation

- Changeover cannot be made with a user interface whose display shows "changeover under centralised control" (refer to installation and operation manual of the user interface).
- When the display "changeover under centralised control" flashes, refer to ["6.5.1 About setting the master user interface"](#) [p. 8].
- The fan may keep on running for about 1 minute after the heating operation stops.
- The air flow rate may adjust itself depending on the room temperature or the fan may stop immediately. This is not a malfunction.

#### 6.2.3 About the heating operation

It may take longer to reach the set temperature for general heating operation than for cooling operation.

The following operation is performed in order to prevent the heating capacity from dropping or cold air from blowing.

##### Defrost operation

In heating operation, freezing of the outdoor unit's air cooled coil increases over time, restricting the energy transfer to the outdoor unit's coil. Heating capability decreases and the system needs to go into defrost operation to be able to remove frost from the outdoor unit's coil. During defrost operation the heating capacity on the indoor unit side will temporarily drop until defrosting is completed. After defrosting, the unit will regain its full heating capacity.

The indoor unit will indicate defrost operation on the display .

##### Hot start

In order to prevent cold air from blowing out of an indoor unit at the start of heating operation, the indoor fan is automatically stopped. The display of the user interface shows . It may take some time before the fan starts. This is not a malfunction.

#### 6.2.4 To operate the system (WITHOUT cool/heat changeover remote control switch)

- 1 Press the operation mode selector button on the user interface several times and select the operation mode of your choice.


- Cooling operation
- Heating operation
- Fan only operation

- 2 Press the ON/OFF button on the user interface.

**Result:** The operation lamp lights up and the system starts operating.

#### 6.2.5 To operate the system (WITH cool/heat changeover remote control switch)

##### Overview of the changeover remote control switch



**a** FAN ONLY/AIR CONDITIONING SELECTOR SWITCH

Set the switch to for fan only operation or to for heating or cooling operation.

**b** COOL/HEAT CHANGEOVER SWITCH

Set the switch to for cooling or to for heating

**Note:** In case a cool/heat changeover remote control switch is used, the position of DIP switch 1 (DS1-1) on the main PCB needs to be switched to the ON position.

##### To start

- 1 Select operation mode with the cool/heat changeover switch as follows:




Cooling operation



Heating operation



Fan only operation



- 2 Press the ON/OFF button on the user interface.

**Result:** The operation lamp lights up and the system starts operating.

##### To stop

- 3 Press the ON/OFF button on the user interface once again.

**Result:** The operation lamp goes out and the system stops operating.



##### NOTICE

Do not turn off power immediately after the unit stops, but wait for at least 5 minutes.

## 6 Operation

### To adjust

For programming temperature, fan speed and air flow direction refer to the operation manual of the user interface.


## 6.3 Using the dry program

### 6.3.1 About the dry program

- The function of this program is to decrease the humidity in your room with minimal temperature decrease (minimal room cooling).
- The micro computer automatically determines temperature and fan speed (cannot be set by the user interface).
- The system does not go into operation if the room temperature is low (<20°C).

### 6.3.2 To use the dry program (WITHOUT cool/heat changeover remote control switch)

#### To start

- 1 Press the operation mode selector button on the user interface several times and select  (program dry operation).
- 2 Press the ON/OFF button of the user interface.  
**Result:** The operation lamp lights up and the system starts operating.
- 3 Press the air flow direction adjust button (only for double-flow, multi-flow, corner, ceiling-suspended and wall-mounted). Refer to "6.4 Adjusting the air flow direction" [p. 8] for details.

#### To stop

- 4 Press the ON/OFF button on the user interface once again.

**Result:** The operation lamp goes out and the system stops operating.




#### NOTICE


Do not turn off power immediately after the unit stops, but wait for at least 5 minutes.

### 6.3.3 To use the dry program (WITH cool/heat changeover remote control switch)

#### To start

- 1 Select cooling operation mode with the cool/heat changeover remote control switch.



- 2 Press the operation mode selector button on the user interface several times and select  (program dry operation).
- 3 Press the ON/OFF button of the user interface.

**Result:** The operation lamp lights up and the system starts operating.

- 4 Press the air flow direction adjust button (only for double-flow, multi-flow, corner, ceiling-suspended and wall-mounted). Refer to "6.4 Adjusting the air flow direction" [p. 8] for details.

#### To stop

- 5 Press the ON/OFF button on the user interface once again.

**Result:** The operation lamp goes out and the system stops operating.



#### NOTICE





Do not turn off power immediately after the unit stops, but wait for at least 5 minutes.

## 6.4 Adjusting the air flow direction

Refer to the operation manual of the user interface.

### 6.4.1 About the air flow flap



Air flow flap types:

-  Double flow + multi-flow units
-  Corner units
-  Ceiling suspended units
-  Wall-mounted units

For the following conditions, a micro computer controls the air flow direction which may be different from the display.

Cooling	Heating
<ul style="list-style-type: none"><li>▪ When the room temperature is lower than the set temperature.</li></ul>	<ul style="list-style-type: none"><li>▪ When starting operation.</li><li>▪ When the room temperature is higher than the set temperature.</li><li>▪ At defrost operation.</li></ul>
<ul style="list-style-type: none"><li>▪ When operating continuously at horizontal air flow direction.</li><li>▪ When continuous operation with downward air flow is performed at the time of cooling with a ceiling-suspended or a wall-mounted unit, the micro computer may control the flow direction, and then the user interface indication will also change.</li></ul>	

The air flow direction can be adjusted in one of the following ways:

- The air flow flap itself adjusts its position.
- The air flow direction can be fixed by the user.
- Automatic  and desired position .




#### WARNING

NEVER touch the air outlet or the horizontal blades while the swing flap is in operation. Fingers may become caught or the unit may break down.



#### NOTICE

- The movable limit of the flap is changeable. Contact your dealer for details. (only for double-flow, multi-flow, corner, ceiling-suspended and wall-mounted).
- Avoid operating in the horizontal direction . It may cause dew or dust to settle on the ceiling or flap.

## 6.5 Setting the master user interface


### 6.5.1 About setting the master user interface



#### INFORMATION

The following figure is an example and may NOT completely match your system layout.





When the system is installed as shown in the figure above, it is necessary to designate one of the user interfaces as the master user interface.

The displays of slave user interfaces show (changeover under centralised control) and slave user interfaces automatically follow the operation mode directed by the master user interface.

Only the master user interface can select heating or cooling mode (cooling/heating masterhood).

## 7 Maintenance and service



### WARNING

NEVER replace a fuse with a fuse of a wrong ampere ratings or other wires when a fuse blows out. Use of wire or copper wire may cause the unit to break down or cause a fire.



### CAUTION

Do NOT insert fingers, rods or other objects into the air inlet or outlet. Do NOT remove the fan guard. When the fan is rotating at high speed, it will cause injury.



### CAUTION

After a long use, check the unit stand and fitting for damage. If damaged, the unit may fall and result in injury.



### NOTICE

NEVER inspect or service the unit by yourself. Ask a qualified service person to perform this work.



### NOTICE

Do NOT wipe the controller operation panel with benzine, thinner, chemical dust cloth, etc. The panel may get discoloured or the coating peeled off. If it is heavily dirty, soak a cloth in water-diluted neutral detergent, squeeze it well and wipe the panel clean. Wipe it with another dry cloth.

### 7.1 About the refrigerant

This product contains fluorinated greenhouse gases. Do NOT vent gases into the atmosphere.

Refrigerant type: R410A

Global warming potential (GWP) value: 2087.5



### NOTICE

Applicable legislation on **fluorinated greenhouse gases** requires that the refrigerant charge of the unit is indicated both in weight and CO<sub>2</sub> equivalent.

**Formula to calculate the quantity in CO<sub>2</sub> equivalent tonnes:** GWP value of the refrigerant × total refrigerant charge [in kg]/1000

Contact your installer for more information.



### WARNING

- The refrigerant in the system is safe and normally does NOT leak. If the refrigerant leaks in the room, contact with a fire of a burner, a heater or a cooker may result in a harmful gas.
- Turn OFF any combustible heating devices, ventilate the room and contact the dealer where you purchased the unit.
- Do NOT use the system until a service person confirms that the portion where the refrigerant leaks is repaired.

## 7.2 After-sales service and warranty

### 7.2.1 Warranty period

- This product includes a warranty card that was filled in by the dealer at the time of installation. The completed card has to be checked by the customer and stored carefully.
- If repairs to the product are necessary within the warranty period, contact your dealer and keep the warranty card at hand.

### 7.2.2 Recommended maintenance and inspection

Since dust collects when using the unit for several years, performance of the unit will deteriorate to some extent. As taking apart and cleaning interiors of units requires technical expertise and in order to ensure the best possible maintenance of your units, we recommend to enter into a maintenance and inspection contract on top of normal maintenance activities. Our network of dealers has access to a permanent stock of essential components in order to keep your unit in operation as long as possible. Contact your dealer for more information.

**When asking your dealer for an intervention, always state:**

- The complete model name of the unit.
- The manufacturing number (stated on the nameplate of the unit).
- The installation date.
- The symptoms or malfunction, and details of the defect.



### WARNING

- Do NOT modify, disassemble, remove, reinstall or repair the unit yourself as incorrect dismantling or installation may cause an electrical shock or fire. Contact your dealer.
- In case of accidental refrigerant leaks, make sure there are no naked flames. The refrigerant itself is entirely safe, non-toxic and non-combustible, but it will generate toxic gas when it accidentally leaks into a room where combustion air from fan heaters, gas cookers, etc. is present. ALWAYS have qualified service personnel confirm that the point of leakage has been repaired or corrected before resuming operation.

## 8 Troubleshooting

If one of the following malfunctions occurs, take the measures shown below and contact your dealer.

## 8 Troubleshooting



### WARNING


**Stop operation and shut OFF the power if anything unusual occurs (burning smells etc.).**

Leaving the unit running under such circumstances may cause breakage, electrical shock or fire. Contact your dealer.

The system **MUST** be repaired by a qualified service person.

Malfunction	Measure
If a safety device such as a fuse, a breaker or an earth leakage breaker frequently actuates or the ON/OFF switch does NOT properly work.	Turn OFF the main power switch.
If water leaks from the unit.	Stop the operation.
The operation switch does NOT work well.	Turn OFF the power supply.
If the user interface display indicates the unit number, the operation lamp flashes and the malfunction code appears.	Notify your installer and report the malfunction code.

If the system does NOT operate properly except for the above mentioned cases and none of the above mentioned malfunctions is evident, investigate the system in accordance with the following procedures.

Malfunction	Measure
If the system does not operate at all.	<ul style="list-style-type: none"> <li>Check if there is no power failure. Wait until power is restored. If power failure occurs during operation, the system automatically restarts immediately after power is restored.</li> <li>Check if no fuse has blown or breaker is activated. Change the fuse or reset the breaker if necessary.</li> </ul>
If the system goes into fan only operation, but as soon as it goes into heating or cooling operation, the system stops.	<ul style="list-style-type: none"> <li>Check if air inlet or outlet of outdoor or indoor unit is not blocked by obstacles. Remove any obstacles and make sure the air can flow freely.</li> <li>Check if the user interface display shows  (time to clean the air filter). (Refer to "7 Maintenance and service" [p. 9] and "Maintenance" in the indoor unit manual.)</li> </ul>
The system operates but cooling or heating is insufficient.	<ul style="list-style-type: none"> <li>Check if air inlet or outlet of outdoor or indoor unit is not blocked by obstacles. Remove any obstacles and make sure the air can flow freely.</li> <li>Check if the air filter is not clogged (refer to "Maintenance" in the indoor unit manual).</li> <li>Check the temperature setting.</li> <li>Check the fan speed setting on your user interface.</li> <li>Check for open doors or windows. Close doors and windows to prevent wind from coming in.</li> <li>Check if there are too many occupants in the room during cooling operation. Check if the heat source of the room is excessive.</li> <li>Check if direct sunlight enters the room. Use curtains or blinds.</li> <li>Check if the air flow angle is proper.</li> </ul>

After checking all the items above, if it is impossible to fix the problem yourself, contact your installer and state the symptoms, the complete model name of the unit (with manufacturing number if possible) and the installation date.

## 8.1 Error codes: Overview

In case a malfunction code appears on the indoor unit user interface display, contact your installer and inform the malfunction code, the unit type, and serial number (you can find this information on the nameplate of the unit).

For your reference, a list with malfunction codes is provided. You can, depending on the level of the malfunction code, reset the code by pushing the ON/OFF button. If not, ask your installer for advice.

Main code	Contents
<i>R0</i>	External protection device was activated
<i>R1</i>	EEPROM failure (indoor)
<i>R3</i>	Drain system malfunction (indoor)
<i>R6</i>	Fan motor malfunction (indoor)
<i>R7</i>	Swing flap motor malfunction (indoor)
<i>R9</i>	Expansion valve malfunction (indoor)
<i>RF</i>	Drain malfunction (indoor unit)
<i>RH</i>	Filter dust chamber malfunction (indoor)
<i>RJ</i>	Capacity setting malfunction (indoor)
<i>C1</i>	Transmission malfunction between main PCB and sub PCB (indoor)
<i>C4</i>	Heat exchanger thermistor malfunction (indoor; liquid)
<i>C5</i>	Heat exchanger thermistor malfunction (indoor; gas)
<i>C9</i>	Suction air thermistor malfunction (indoor)
<i>CR</i>	Discharge air thermistor malfunction (indoor)
<i>CE</i>	Movement detector or floor temperature sensor malfunction (indoor)
<i>CJ</i>	User interface thermistor malfunction (indoor)
<i>E1</i>	PCB malfunction (outdoor)
<i>E2</i>	Current leakage detector was activated (outdoor)
<i>E3</i>	High pressure switch was activated
<i>E4</i>	Low pressure malfunction (outdoor)
<i>E5</i>	Compressor lock detection (outdoor)
<i>E7</i>	Fan motor malfunction (outdoor)
<i>E9</i>	Electronic expansion valve malfunction (outdoor)
<i>F3</i>	Discharge temperature malfunction (outdoor)
<i>F4</i>	Abnormal suction temperature (outdoor)
<i>F6</i>	Refrigerant overcharge detection
<i>H3</i>	High pressure switch malfunction
<i>H4</i>	Low pressure switch malfunction
<i>H7</i>	Fan motor trouble (outdoor)
<i>H9</i>	Ambient temperature sensor malfunction (outdoor)
<i>J1</i>	Pressure sensor malfunction
<i>J2</i>	Current sensor malfunction
<i>J3</i>	Discharge temperature sensor malfunction (outdoor)
<i>J4</i>	Heat exchanger gas temperature sensor malfunction (outdoor)
<i>J5</i>	Suction temperature sensor malfunction (outdoor)
<i>J6</i>	De-icing temperature sensor malfunction (outdoor)
<i>J7</i>	Liquid temperature sensor (after subcool HE) malfunction (outdoor)
<i>J8</i>	Liquid temperature sensor (coil) malfunction (outdoor)
<i>J9</i>	Gas temperature sensor (after subcool HE) malfunction (outdoor)
<i>JA</i>	High pressure sensor malfunction (S1NPH)
<i>JC</i>	Low pressure sensor malfunction (S1NPL)
<i>L1</i>	INV PCB abnormal
<i>L4</i>	Fin temperature abnormal

Main code	Contents
L5	Inverter PCB faulty
L8	Compressor over current detected
L9	Compressor lock (startup)
LC	Transmission outdoor unit - inverter: INV transmission trouble
P1	INV unbalanced power supply voltage
P2	Autocharge operation related
P4	Fin thermistor malfunction
P8	Autocharge operation related
P9	Autocharge operation related
PE	Autocharge operation related
PJ	Capacity setting malfunction (outdoor)
U0	Abnormal low pressure drop, faulty expansion valve
U1	Reversed power supply phase malfunction
U2	INV voltage power shortage
U3	System test run not yet executed
U4	Faulty wiring indoor/outdoor
U5	Abnormal user interface - indoor communication
U7	Faulty wiring to outdoor/outdoor
U8	Abnormal main-sub user interface communication
U9	System mismatch. Wrong type of indoor units combined. Indoor unit malfunction.
UR	Connection malfunction over indoor units or type mismatch
UC	Centralised address duplication
UE	Malfunction in communication centralised control device - indoor unit
UF	Auto address malfunction (inconsistency)
UH	Auto address malfunction (inconsistency)

## 8.2 Symptoms that are NOT system malfunctions


The following symptoms are NOT system malfunctions:

### 8.2.1 Symptom: The system does not operate

- The air conditioner does not start immediately after the ON/OFF button on the user interface is pressed. If the operation lamp lights, the system is in normal condition. To prevent overloading of the compressor motor, the air conditioner starts 5 minutes after it is turned ON again in case it was turned OFF just before. The same starting delay occurs after the operation mode selector button was used.
- If "Under Centralised Control" is displayed on the user interface, pressing the operation button causes the display to blink for a few seconds. The blinking display indicates that the user interface cannot be used.
- The system does not start immediately after the power supply is turned on. Wait one minute until the microcomputer is prepared for operation.

### 8.2.2 Symptom: Cool/Heat cannot be changed over

- When the display shows  (changeover under centralised control), it shows that this is a slave user interface.

- When the cool/heat changeover remote control switch is installed and the display shows  (changeover under centralised control), this is because cool/heat changeover is controlled by the cool/ heat changeover remote control switch. Ask your dealer where the remote control switch is installed.

### 8.2.3 Symptom: Fan operation is possible, but cooling and heating do not work

Immediately after the power is turned on. The micro computer is getting ready to operate and is performing a communication check with the indoor unit(s). Please wait 12 minutes maximally until this process is finished.

### 8.2.4 Symptom: The fan speed does not correspond to the setting

The fan speed does not change even if the fan speed adjustment button is pressed. During heating operation, when the room temperature reaches the set temperature, the outdoor unit goes off and the indoor unit changes to whisper fan speed. This is to prevent cold air blowing directly on occupants of the room. The fan speed will not change even when another indoor unit is in heating operation, if the button is pressed.

### 8.2.5 Symptom: The fan direction does not correspond to the setting

The fan direction does not correspond with the user interface display. The fan direction does not swing. This is because the unit is being controlled by the micro computer.

### 8.2.6 Symptom: White mist comes out of a unit (Indoor unit)

- When humidity is high during cooling operation. If the interior of an indoor unit is extremely contaminated, the temperature distribution inside a room becomes uneven. It is necessary to clean the interior of the indoor unit. Ask your dealer for details on cleaning the unit. This operation requires a qualified service person.
- Immediately after the cooling operation stops and if the room temperature and humidity are low. This is because warm refrigerant gas flows back into the indoor unit and generates steam.

### 8.2.7 Symptom: White mist comes out of a unit (Indoor unit, outdoor unit)

When the system is changed over to heating operation after defrost operation. Moisture generated by defrost becomes steam and is exhausted.

### 8.2.8 Symptom: The user interface reads "U4" or "U5" and stops, but then restarts after a few minutes

This is because the user interface is intercepting noise from electric appliances other than the air conditioner. The noise prevents communication between the units, causing them to stop. Operation automatically restarts when the noise ceases. A power reset may help to remove this error.

### 8.2.9 Symptom: Noise of air conditioners (Indoor unit)

- A "zeen" sound is heard immediately after the power supply is turned on. The electronic expansion valve inside an indoor unit starts working and makes the noise. Its volume will reduce in about one minute.

## 9 Relocation

- A continuous low "shah" sound is heard when the system is in cooling operation or at a stop. When the drain pump (optional accessories) is in operation, this noise is heard.
- A "pishi-pishi" squeaking sound is heard when the system stops after heating operation. Expansion and contraction of plastic parts caused by temperature change make this noise.
- A low "sah", "choro-choro" sound is heard while the indoor unit is stopped. When another indoor unit is in operation, this noise is heard. In order to prevent oil and refrigerant from remaining in the system, a small amount of refrigerant is kept flowing.

### 8.2.10 Symptom: Noise of air conditioners (Indoor unit, outdoor unit)

- A continuous low hissing sound is heard when the system is in cooling or defrost operation. This is the sound of refrigerant gas flowing through both indoor and outdoor units.
- A hissing sound which is heard at the start or immediately after stopping operation or defrost operation. This is the noise of refrigerant caused by flow stop or flow change.

### 8.2.11 Symptom: Noise of air conditioners (Outdoor unit)

When the tone of operating noise changes. This noise is caused by the change of frequency.

### 8.2.12 Symptom: Dust comes out of the unit

When the unit is used for the first time in a long time. This is because dust has gotten into the unit.

### 8.2.13 Symptom: The units can give off odours

The unit can absorb the smell of rooms, furniture, cigarettes, etc., and then emit it again.

### 8.2.14 Symptom: The outdoor unit fan does not spin

During operation, the speed of the fan is controlled in order to optimise product operation.

### 8.2.15 Symptom: The display shows "88"

This is the case immediately after the main power supply switch is turned on and means that the user interface is in normal condition. This continues for 1 minute.

### 8.2.16 Symptom: The compressor in the outdoor unit does not stop after a short heating operation

This is to prevent refrigerant from remaining in the compressor. The unit will stop after 5 to 10 minutes.

### 8.2.17 Symptom: The inside of an outdoor unit is warm even when the unit has stopped

This is because the crankcase heater is warming the compressor so that the compressor can start smoothly.

### 8.2.18 Symptom: Hot air can be felt when the indoor unit is stopped

Several different indoor units are being run on the same system. When another unit is running, some refrigerant will still flow through the unit.

## 9 Relocation

Contact your dealer to remove and reinstall the entire unit. Moving units requires technical expertise.

## 10 Disposal

This unit uses hydrofluorocarbon. Contact your dealer when discarding this unit. It is required by law to collect, transport and discard the refrigerant in accordance with the "hydrofluorocarbon collection and destruction" regulations.



#### NOTICE

Do NOT try to dismantle the system yourself: dismantling of the system, treatment of the refrigerant, oil and other parts MUST comply with applicable legislation. Units MUST be treated at a specialised treatment facility for reuse, recycling and recovery.

## For the installer

## 11 About the box

Keep the following in mind:

- At delivery, the unit MUST be checked for damage and completeness. Any damage or missing parts MUST be reported immediately to the claims agent of the carrier.
- Bring the packed unit as close as possible to its final installation position to prevent damage during transport.
- Prepare in advance the path along which you want to bring the unit to its final installation position.



### 11.1 About **LOOP**

**LOOP** is part of Daikin's wider commitment to reduce our environmental footprint. With **LOOP** we want to create a circular economy for refrigerants. One of the actions to achieve this, is the

reuse of reclaimed refrigerant in VRV units produced and sold in Europe. For more information about the countries that are in scope, visit: <http://www.daikin.eu/loop-by-daikin>.

### 11.2 To remove the accessories from the outdoor unit

Make sure that all accessories are available in the unit.



## 12 About the units and options

### 11.3 Accessory pipes: Diameters

Accessory pipes (mm)	HP	Øa	Øb
<b>Gas pipe</b>	8	19.1	
▪ Front connection	10	25.4	22.2
▪ Bottom connection	12	25.4	28.6
	14		
<b>Liquid pipe</b>	8	9.5	
▪ Front connection	10		
▪ Bottom connection	12	12.7	
	14		

### 12.1 About the outdoor unit

This installation manual concerns the VRV IV, full inverter driven, heat pump system.

Model line up:

Model	Description
RXYLQ10~14	Single non-continuous heating model.
RXYLQ16~42	Multi non-continuous heating model (consisting of 2 or 3 modules).

Depending on the type of outdoor unit which is chosen, some functionality will or will not exist. It will be indicated throughout this installation manual and brought to your attention. Certain features have exclusive model rights.

These units are intended for outdoor installation and aimed for heat pump applications including air to air and air to water applications.

These units have (in single use) heating capacities ranging from 31.5 to 45 kW and cooling capacities rating from 28 to 40 kW. In multi combination the heating capacity ranges from 50 to 135 kW and cooling capacity ranges from 45 to 120 kW.

The outdoor unit is designed to work in heating mode at ambient temperatures from -25°C WB to 15.5°C WB and in cooling mode at ambient temperatures from -5°C DB to 43°C DB.

### 11.4 To remove the transportation stay



#### NOTICE

If the unit is operated with the transportation stay attached, abnormal vibration or noise may be generated.

The compressor transportation stay must be removed. It is installed under the compressor leg in order to protect the unit during transport. Proceed as shown in the figure and procedure below.


- 1 Remove the 2 transportation stay mounting bolts.
- 2 Remove the transportation stay as shown in the figure below.

### 12.2 System layout



#### INFORMATION

The following figure is an example and may NOT completely match your system layout.



- a VRV IV Heat pump outdoor unit  
b Refrigerant piping  
c VRV direct expansion (DX) indoor unit  
d VRV LT Hydrobox (HXY080/125)  
e BP box (required to connect Residential Air (RA) or Sky Air (SA) direct expansion (DX) indoor units)  
f Residential Air (RA) direct expansion (DX) indoor units  
g User interface (dedicated depending on indoor unit type)  
h User interface (wireless, dedicated depending on indoor unit type)



13 Unit installation

i Cool/heat changeover remote control switch

13 Unit installation

13.1 Preparing the installation site

13.1.1 Installation site requirements of the outdoor unit

Mind the spacing guidelines. See the "Technical data" chapter.



CAUTION

Appliance NOT accessible to the general public, install it in a secured area, protected from easy access.  
This unit, both indoor and outdoor, is suitable for installation in a commercial and light industrial environment.



NOTICE

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.


13.1.2 Additional installation site requirements of the outdoor unit in cold climates



NOTICE

When operating the unit in a low outdoor ambient temperature with high humidity conditions, make sure to take precautions to keep the drain holes of the unit free by using proper equipment.


In heating:



a Warming up operation range  
b Operation range  
 $T_{Ai}$  Ambient indoor temperature  
 $T_{Ao}$  Ambient outdoor temperature



DANGER: RISK OF BURNING/SCALDING




Once the front plates open, the switch box can be accessed. See "13.2.2 To open the switch box of the outdoor unit" [p 14].  
For service purposes, the pushbuttons on the main PCB need to be accessed. To access these pushbuttons, the switch box cover does not need to be opened. See "16.1.3 To access the field setting components" [p 28].

13.2.2 To open the switch box of the outdoor unit




NOTICE

Do NOT apply excessive force when opening the switch box cover. Excessive force can deform the cover, resulting in entering of water to cause equipment failure.



NOTICE

When closing the switch box cover, make sure that the sealing material on the lower back side of the cover is NOT caught and bent towards the inside (see figure below).



- a Switch box cover
- b Front side
- c Power supply terminal block
- d Sealing material
- e Moisture and dirt could enter
- ✗ NOT allowed
- ✓ Allowed

13.3 Mounting the outdoor unit

13.3.1 To provide the installation structure

Make sure the unit is installed level on a sufficiently strong base to prevent vibration and noise.



DANGER: RISK OF ELECTROCUTION







### NOTICE

- When the installation height of the unit needs to be increased, do NOT use stands to only support the corners.
- Stands under the unit must be at least 100 mm wide.




### NOTICE

The height of the foundation must at least be 150 mm from the floor. In heavy snowfall areas, this height should be increased up to the average expected snow level, depending on the installation place and condition.




HP	AA	AB
8~14	1076	1302

- Fasten the unit in place using four foundation bolts M12. It is best to screw in the foundation bolts until their length remains 20 mm above the foundation surface.



### NOTICE

- Prepare a water drainage channel around the foundation to drain waste water from around the unit. During heating operation and when the outdoor temperatures are negative, the drained water from the outdoor unit will freeze up. If the water drainage is not taken care of, the area around the unit might be very slippery.
- When installed in a corrosive environment, use a nut with plastic washer (a) to protect the nut tightening part from rust.



## 14 Piping installation

### 14.1 Preparing refrigerant piping

#### 14.1.1 Refrigerant piping requirements



### NOTICE

Refrigerant R410A requires strict cautions for keeping the system clean and dry. Foreign materials (including mineral oils or moisture) should be prevented from getting mixed into the system.



### NOTICE

The piping and other pressure-containing parts shall be suitable for refrigerant. Use phosphoric acid deoxidised seamless copper for refrigerant piping.


- Only use phosphoric acid deoxidised seamless copper.
- Foreign materials inside pipes (including oils for fabrication) must be ≤30 mg/10 m.
- Temper grade: use piping with temper grade in function of the pipe diameter as listed in table below.

Pipe Ø	Temper grade of piping material
≤15.9 mm	O (annealed)
≥19.1 mm	1/2H (half hard)

- All piping lengths and distances have been taken into consideration (see About the piping length in the installer reference guide).

#### 14.1.2 To select the piping size

Determine the proper size using the following tables for connections to DX indoor units, AHU and Hydrobox (the reference figure is only for indication).



#### A, B, C: Piping between outdoor unit and (first) refrigerant branch kit

Choose from the following table in accordance with the outdoor unit total capacity type, connected downstream.

Outdoor unit capacity type (HP)	Piping outer diameter size [mm]	
	Gas pipe	Liquid pipe
8	19.1	9.5
10	22.2	9.5
12~16	28.6	12.7
18~22	28.6	15.9

## 14 Piping installation

Outdoor unit capacity type (HP)	Piping outer diameter size [mm]	
	Gas pipe	Liquid pipe
24	34.9	15.9
26~34	34.9	19.1
36~42	41.3	19.1

### D: Piping between refrigerant branch kits

Choose from the following table in accordance with the indoor unit total capacity type, connected downstream. Do not let the connection piping exceed the refrigerant piping size chosen by the general system model name.

Indoor unit capacity index	Piping outer diameter size (mm)	
	Gas pipe	Liquid pipe
<150	15.9	9.5
150≤x<200	19.1	
200≤x<290	22.2	
290≤x<420	28.6	12.7
420≤x<640		15.9
640≤x<920	34.9	19.1
≥920	41.3	

#### Example:


- Downstream capacity for E=capacity index of unit 1
- Downstream capacity for D=capacity index of unit 1+capacity index of unit 2

### E: Piping between refrigerant branch kit and indoor unit

Pipe size for direct connection to indoor unit must be the same as the connection size of the indoor unit (in case indoor unit is VRV DX indoor or Hydrobox).

Indoor unit capacity index	Piping outer diameter size (mm)	
	Gas pipe	Liquid pipe
15~50	12.7	6.4
63~140	15.9	9.5
200	19.1	
250	22.2	

- When the equivalent pipe length between outdoor and indoor units is 90 m or more, the size of the main pipes (both gas side and liquid side) must be increased. Depending on the length of the piping, the capacity may drop, but even in such a case the size of the main pipes has to be increased. More specifications can be found in the technical engineering data book.



- a Outdoor unit
- b Main pipes (increase if the equivalent piping length is ≥90 m)
- c First refrigerant branch kit
- d Piping between refrigerant branch kit and indoor unit
- e Indoor unit

Size up		
HP class	Piping outer diameter size (mm)	
	Gas pipe	Liquid pipe
8	19.1 → 22.2	9.5 → 12.7
10	22.2 → 25.4 <sup>(a)</sup>	

Size up		
HP class	Piping outer diameter size (mm)	
	Gas pipe	Liquid pipe
12+14	28.6 <sup>(b)</sup>	12.7 → 15.9
16	28.6 → 31.8 <sup>(a)</sup>	
18~22		15.9 → 19.1
24	34.9 <sup>(b)</sup>	
26~34	34.9 → 38.1 <sup>(a)</sup>	19.1 → 22.2
36~42	41.3 <sup>(b)</sup>	

- <sup>(a)</sup> If the size-up size is NOT available, you must use the standard size. Sizes bigger than the size-up size are NOT allowed. But even if you use the standard size, the equivalent piping length is allowed to be more than 90 m.
- <sup>(b)</sup> Pipe size-up is NOT allowed.

- The pipe thickness of the refrigerant piping shall comply with the applicable legislation. The minimal pipe thickness for R410A piping must be in accordance with the table below.

Pipe Ø (mm)	Minimal thickness t (mm)
6.4/9.5/12.7	0.80
15.9	0.99
19.1/22.2	0.80
28.6	0.99
34.9	1.21
41.3	1.43

- In case the required pipe sizes (inch sizes) are not available, it is also allowed to use other diameters (mm sizes), taken the following into account:
  - Select the pipe size nearest to the required size.
  - Use the suitable adapters for the changeover from inch to mm pipes (field supply).
  - The additional refrigerant calculation has to be adjusted as mentioned in "14.4.3 To determine the additional refrigerant amount" [p. 22].

### F: Piping between refrigerant branch kit and branch selector box (BP box)

Pipe size for direct connection on branch selector box (BP\*) must be based on the total capacity of the connected indoor units (only in case RA DX indoor units are connected).

Total capacity index of connected indoor units	Piping outer diameter size (mm)	
	Gas pipe	Liquid pipe
20~62	12.7	6.4
63~149	15.9	9.5
150~208	19.1	

#### Example:

Downstream capacity for F=[capacity index of unit 4]+[capacity index of unit 5]

### G: Piping between branch selector box (BP box) and RA DX indoor unit

Only in case RA DX indoor units are connected.

Indoor unit capacity index	Piping outer diameter size (mm)	
	Gas pipe	Liquid pipe
20, 25, 30	9.5	6.4
50	12.7	
60		9.5
71	15.9	

### 14.1.3 To select refrigerant branch kits

#### Refrigerant refnets

For piping example, refer to "14.1.2 To select the piping size" [p. 15].

- When using refnet joints at the first branch counted from the outdoor unit side, choose from the following table in accordance with the capacity of the outdoor unit (example: refnet joint a).

Outdoor unit capacity type (HP)	Refrigerant branch kit
8+10	KHRQ22M29T9
12~22	KHRQ22M64T
24~42	KHRQ22M75T

- For refnet joints other than the first branch (example refnet joint b), select the proper branch kit model based on the total capacity index of all indoor units connected after the refrigerant branch.

Indoor unit capacity index	Refrigerant branch kit
<200	KHRQ22M20T
200≤x<290	KHRQ22M29T9
290≤x<640	KHRQ22M64T
≥640	KHRQ22M75T

- Concerning refnet headers, choose from the following table in accordance with the total capacity of all the indoor units connected below the refnet header.

Indoor unit capacity index	Refrigerant branch kit
<200	KHRQ22M29H
200≤x<290	KHRQ22M64H <sup>(a)</sup>
290≤x<640	KHRQ22M64H <sup>(a)</sup>
≥640	KHRQ22M75H

<sup>(a)</sup> If the pipe size above the refnet header is Ø34.9 mm or more, KHRQ22M75H is required.



#### INFORMATION

Maximum 8 branches can be connected to a header.

- How to choose an outdoor multi connection piping kit. Choose from the following table in accordance with the number of outdoor units.

Number of outdoor units	Branch kit name
2	BHFQ22P1007
3	BHFQ22P1517



#### INFORMATION

Reducers or T-joints are field supplied.





#### NOTICE

Refrigerant branch kits can only be used with R410A.



### 14.1.4 Multiple outdoor units: Possible layouts

- The piping between the outdoor units must be routed level or slightly upward to avoid the risk of oil retention into the piping.




- a To indoor unit
- b Piping between outdoor units
- NOT allowed (oil remains in piping)
- Allowed

- To avoid the risk of oil retention to the outmost outdoor unit, always connect the stop valve and the piping between outdoor units as shown in the correct (✓) possibilities of the figure below.



- a To indoor unit
- b Oil collects to the outmost outdoor unit when the system stops
- NOT allowed (oil remains in piping)
- Allowed

- If the piping length between the outdoor units exceeds 2 m, create a rise of 200 mm or more in the gas line within a length of 2 m from the kit.




- a To indoor unit
- b Piping between outdoor units

## 14 Piping installation



### NOTICE

There are restrictions on the refrigerant pipe connection order between outdoor units during installation in case of a multiple outdoor unit system. Install according to following restrictions. The capacities of outdoor units A, B and C must fulfill the following restriction conditions:  $A \geq B \geq C$ .



a To indoor units


b Outdoor unit multi connecting piping kit (first branch)

c Outdoor unit multi connecting piping kit (second branch)

## 14.2 Connecting the refrigerant piping

### 14.2.1 To route the refrigerant piping

Installation of refrigerant piping is possible as front connection or side connection (when taken out from the bottom) as shown in the figure below.




a Left-side connection

b Front connection

c Right-side connection

**Note:** For side connections, remove the knockout hole on the bottom plate as shown below:



a Large knockout hole

b Drill

c Points for drilling



### NOTICE

Precautions when making knockout holes:

- Avoid damaging the casing.
- After making the knockout holes, we recommend you remove the burrs and paint the edges and areas around the edges using repair paint to prevent rusting.
- When passing electrical wiring through the knockout holes, wrap the wiring with protective tape to prevent damage.

### 14.2.2 To connect the refrigerant piping to the outdoor unit



### NOTICE

- Be sure to use the supplied accessory pipes when carrying out piping work in the field.
- Be sure that the field installed piping does not touch other pipes, the bottom panel or side panel. Especially for the bottom and side connection, be sure to protect the piping with suitable insulation, to prevent it from coming into contact with the casing.

Connect the stop valves to the field piping using the accessory pipes supplied with the unit.

The connections to the branch kits are the responsibility of the installer (field piping).


### 14.2.3 To connect the multi connection piping kit




### NOTICE

Improper installation may lead to malfunction of the outdoor unit.

- Install the joints horizontally, so that the caution label (a) attached to the joint comes to the top.
  - Do not tilt the joint more than 7.5° (see view A).
  - Do not install the joint vertically (see view B).




- Make sure that the total length of the piping connected to the joint is absolute straight for more than 500 mm. Only if a straight field piping of more than 120 mm is connected, more than 500 mm of straight section can be ensured.



### 14.2.4 To connect the refrigerant branching kit

For installation of the refrigerant branching kit, refer to the installation manual delivered with the kit.

- Mount the refnet joint so that it branches either horizontally or vertically.
- Mount the refnet header so that it branches horizontally.



## 14.2.5 To protect against contamination

Seal the piping and wiring intake holes using sealing material (field supply), otherwise the capacity of the unit will drop and small animals may enter the machine.

## 14.2.6 Using the stop valve and service port


### To handle the stop valve

Take the following guidelines into account:

- The gas and liquid stop valves are factory closed.
- Make sure to keep all stop valves open during operation.
- Do NOT apply excessive force to the stop valve. Doing so may break the valve body.

### To open the stop valve

- 1 Remove the stop valve cover.
- 2 Insert a hexagon wrench into the stop valve and turn the stop valve counterclockwise.



- 3 When the stop valve cannot be turned any further, stop turning.
- 4 Install the stop valve cover.

**Result:** The valve is now open.

To fully open the Ø19.1~Ø25.4 mm stop valve, turn the hexagonal wrench until a torque between 27 and 33 N•m is achieved.

Inadequate torque may cause leakage of refrigerant and breakage of the stop valve cap.



### NOTICE

Pay attention that mentioned torque range is applicable for opening Ø19.1~Ø25.4 mm stop valves only.

### To close the stop valve


- 1 Remove the stop valve cover.

- 2 Insert a hexagon wrench into the stop valve and turn the stop valve clockwise.
- 3 When the stop valve cannot be turned any further, stop turning.
- 4 Install the stop valve cover.

**Result:** The valve is now closed.

### To handle the stop valve cover

- The stop valve cover is sealed where indicated by the arrow. Do NOT damage it.
- After handling the stop valve, tighten the stop valve cover securely, and check for refrigerant leaks. For the tightening torque, refer to the table below.



### To handle the service port

- Always use a charge hose equipped with a valve depressor pin, since the service port is a Schrader type valve.
- After handling the service port, make sure to tighten the service port cover securely. For the tightening torque, refer to the table below.
- Check for refrigerant leaks after tightening the service port cover.

### Tightening torques

Stop valve size [mm]	Tightening torque [N•m] (turn clockwise to close)			
	Shaft			
	Valve body	Hexagonal wrench	Cap (valve lid)	Service port
Ø9.5	5.4~6.6	4 mm	13.5~16.5	11.5~13.9
Ø12.7	8.1~9.9		18.0~22.0	
Ø15.9	13.5~16.5	6 mm	23.0~27.0	
Ø19.1	27.0~33.0		22.5~27.5	
Ø25.4				

## 14.2.7 To remove the spun pipes




### WARNING

Any gas or oil remaining inside the stop valve may blow off the spun piping.


If these instructions are NOT followed correctly it may result in property damage or personal injury, which may be serious depending on the circumstances.

Use the following procedure to remove the spun piping:

- 1 Make sure that the stop valves are fully closed.



- 2 Connect the vacuuming/recovery unit through a manifold to the service port of all stop valves.



## 14 Piping installation

- c Weighing scales
- d Refrigerant R410A tank (siphon system)
- e Vacuum pump
- f Liquid line stop valve
- g Gas line stop valve
- A Valve A
- B Valve B

- 3 Recover gas and oil from the spun piping by using a recovery unit.



### CAUTION

Do NOT vent gases into the atmosphere.

- 4 When all gas and oil is recovered from the spun piping, disconnect the charge hose and close the service ports.
- 5 Cut off the lower part of the gas, liquid and equalising stop valve pipes along the black line. Use an appropriate tool (e.g. a pipe cutter).



### WARNING




NEVER remove the spun piping by brazing.

Any gas or oil remaining inside the stop valve may blow off the spun piping.

- 6 Wait until all oil has dripped out before continuing with the connection of the field piping in case the recovery was not complete.

## 14.3 Checking the refrigerant piping

### 14.3.1 About checking the refrigerant piping



It is very important that all refrigerant piping work is done before the units (outdoor or indoor) are powered on. When the units are powered on, the expansion valves will initialise. This means that the valves will close.



### NOTICE

Leak test and vacuum drying of field piping and indoor units is impossible when field expansion valves are closed.

### Method 1: Before power ON

If the system has not yet been powered on, no special action is required to perform the leak test and the vacuum drying.

### Method 2: After power ON

If the system has already been powered on, activate setting [2-21] (refer to "16.1.4 To access mode 1 or 2" [p 29]). This setting will open field expansion valves to guarantee a refrigerant piping pathway and make it possible to perform the leak test and the vacuum drying.



### DANGER: RISK OF ELECTROCUTION



### NOTICE

Make sure that all indoor units connected to the outdoor unit are powered on.



### NOTICE

Wait to apply setting [2-21] until the outdoor unit has finished the initialisation.

### Leak test and vacuum drying

Checking the refrigerant piping involves:

- Checking for any leakages in the refrigerant piping.
- Performing vacuum drying to remove all moisture, air or nitrogen in the refrigerant piping.

If there is a possibility of moisture being present in the refrigerant piping (for example, water may have entered the piping), first carry out the vacuum drying procedure below until all moisture has been removed.

All piping inside the unit has been factory tested for leaks.

Only field installed refrigerant piping needs to be checked. Therefore, make sure that all the outdoor unit stop valves are firmly closed before performing leak test or vacuum drying.



### NOTICE

Make sure that all (field supplied) field piping valves are OPEN (not outdoor unit stop valves!) before you start leak test and vacuuming.

For more information on the state of the valves, refer to "14.3.3 Checking refrigerant piping: Setup" [p 21].

### 14.3.2 Checking refrigerant piping: General guidelines

Connect the vacuum pump through a manifold to the service port of all stop valves to increase efficiency (refer to "14.3.3 Checking refrigerant piping: Setup" [p 21]).



### NOTICE

Use a 2-stage vacuum pump with a non-return valve or a solenoid valve that can evacuate to a gauge pressure of  $-100.7 \text{ kPa}$  ( $-1.007 \text{ bar}$ ).



### NOTICE

Make sure the pump oil does not flow oppositely into the system while the pump is not working.




### NOTICE

Do NOT purge the air with refrigerants. Use a vacuum pump to evacuate the installation.



### 14.3.3 Checking refrigerant piping: Setup



- a Pressure reducing valve
- b Nitrogen
- c Weighing scales
- d Refrigerant R410A tank (siphon system)
- e Vacuum pump
- f Liquid line stop valve
- g Gas line stop valve
- A Valve A
- B Valve B
- C Valve C

Valve	Status
Valve A	Open
Valve B	Open
Valve C	Open
Liquid line stop valve	Close
Gas line stop valve	Close



#### NOTICE

The connections to the indoor units and all indoor units should also be leak and vacuum tested. Keep any possible (field supplied) field piping valves open as well.

Refer to the indoor unit installation manual for more details. Leak test and vacuum drying should be done before the power supply is set to the unit. If not, see also the flow chart earlier described in this chapter (see "14.3.1 About checking the refrigerant piping" [p 20]).

### 14.3.4 To perform a leak test

The leak test must satisfy the specifications of EN378-2.

#### Vacuum leak test

- 1 Evacuate the system from the liquid and gas piping to a gauge pressure of  $-100.7 \text{ kPa}$  ( $-1.007 \text{ bar}$ ) for more than 2 hours.
- 2 Once reached, turn off the vacuum pump and check that the pressure does not rise for at least 1 minute.
- 3 Should the pressure rise, the system may either contain moisture (see vacuum drying below) or have leaks.

#### Pressure leak test

- 1 Break the vacuum by pressurising with nitrogen gas to a minimum gauge pressure of  $0.2 \text{ MPa}$  (2 bar). Never set the gauge pressure higher than the maximum operation pressure of the unit, i.e.  $4.0 \text{ MPa}$  (40 bar).
- 2 Test for leaks by applying a bubble test solution to all piping connections.
- 3 Discharge all nitrogen gas.



#### NOTICE

ALWAYS use a recommended bubble test solution from your wholesaler.

NEVER use soap water:

- Soap water may cause cracking of components, such as flare nuts or stop valve caps.
- Soap water may contain salt, which absorbs moisture that will freeze when the piping gets cold.
- Soap water contains ammonia which may lead to corrosion of flared joints (between the brass flare nut and the copper flare).

### 14.3.5 To perform vacuum drying

To remove all moisture from the system, proceed as follows:

- 1 Evacuate the system for at least 2 hours to a target vacuum of  $-100.7 \text{ kPa}$  ( $-1.007 \text{ bar}$ ) (5 Torr absolute).
- 2 Check that, with the vacuum pump turned off, the target vacuum is maintained for at least 1 hour.
- 3 Should you fail to reach the target vacuum within 2 hours or maintain the vacuum for 1 hour, the system may contain too much moisture. In that case, break the vacuum by pressurising with nitrogen gas to a gauge pressure of  $0.05 \text{ MPa}$  (0.5 bar) and repeat steps 1 to 3 until all moisture has been removed.
- 4 Depending on whether you want to immediately charge refrigerant through the refrigerant charge port or first pre-charge a portion of refrigerant through the liquid line, either open the outdoor unit stop valves, or keep them closed. See "14.4.2 About charging refrigerant" [p 22] for more information.


### 14.3.6 To insulate the refrigerant piping

After finishing the leak test and vacuum drying, the piping must be insulated. Take into account the following points:

- Make sure to insulate the connection piping and refrigerant branch kits entirely.
- Be sure to insulate the liquid and gas piping (for all units).
- Use heat resistant polyethylene foam which can withstand a temperature of  $70^\circ\text{C}$  for liquid piping and polyethylene foam which can withstand a temperature of  $120^\circ\text{C}$  for gas piping.
- Reinforce the insulation on the refrigerant piping according to the installation environment.

Ambient temperature	Humidity	Minimum thickness
$\leq 30^\circ\text{C}$	75% to 80% RH	15 mm
$> 30^\circ\text{C}$	$\geq 80\%$ RH	20 mm

- If there is a possibility that condensation on the stop valve might drip down into the indoor unit through gaps in the insulation and piping because the outdoor unit is located higher than the indoor unit, this must be prevented by sealing up the connections. See below figure.



- a Insulation material
- b Caulking etc.

## 14 Piping installation

### 14.4 Charging refrigerant

#### 14.4.1 Precautions when charging refrigerant



##### WARNING

- ONLY use R410A as refrigerant. Other substances may cause explosions and accidents.
- R410A contains fluorinated greenhouse gases. Its global warming potential (GWP) value is 2087.5. Do NOT vent these gases into the atmosphere.
- When charging refrigerant, ALWAYS use protective gloves and safety glasses.



##### NOTICE

If the power of some units is turned off, the charging procedure cannot be finished properly.



##### NOTICE

In case of a multiple outdoor system, turn on the power of all outdoor units.



##### NOTICE

Turn ON the power 6 hours before operation in order to have power running to the crankcase heater and to protect the compressor.



##### NOTICE

If operation is performed within 12 minutes after the indoor and outdoor unit(s) are powered on, the compressor will not operate before the communication is established in a correct way between outdoor unit(s) and indoor unit(s).



##### NOTICE

Before starting charging procedures, check if the 7-segment display indication of the outdoor unit A1P PCB is as normal (see "16.1.4 To access mode 1 or 2" ▶ 29). If a malfunction code is present, see "19.1 Solving problems based on error codes" ▶ 33.



##### NOTICE

Close the front panel before any refrigerant charge operation is executed. Without the front panel attached the unit cannot judge correctly whether it is operating properly or not.



##### NOTICE

In case of maintenance and the system (outdoor unit+field piping+indoor units) does not contain any refrigerant any more (e.g., after refrigerant reclaim operation), the unit has to be charged with its original amount of refrigerant (refer to the nameplate on the unit) by pre-charging before the automatic charging function can be started.

#### 14.4.2 About charging refrigerant

Once vacuum drying is finished, additional refrigerant charging can start.

To speed up the refrigerant charging process, it is in case of larger systems recommended to first pre-charge a portion of refrigerant through the liquid line before proceeding with the manual charging.

#### 14.4.4 To charge refrigerant: Flow chart

For more information, see "14.4.5 To charge refrigerant" ▶ 24.

This step is included in below procedure (see "14.4.5 To charge refrigerant" ▶ 24). It can be skipped, but charging will take longer then.

A flow chart is available which gives an overview of the possibilities and actions to be taken (see "14.4.4 To charge refrigerant: Flow chart" ▶ 22).

#### 14.4.3 To determine the additional refrigerant amount



##### INFORMATION

For final charge adjustment in the test laboratory, please contact your local dealer.



##### NOTICE

The refrigerant charge of the system must be less than 100 kg. This means that in case the calculated total refrigerant charge is equal to or more than 95 kg you must divide your multiple outdoor system into smaller independent systems, each containing less than 95 kg refrigerant charge. For factory charge, refer to the unit name plate.

##### Formula:

$$R = [(X_1 \times \mathbf{022.2}) \times 0.37 + (X_2 \times \mathbf{019.1}) \times 0.26 + (X_3 \times \mathbf{015.9}) \times 0.18 + (X_4 \times \mathbf{012.7}) \times 0.12 + (X_5 \times \mathbf{09.5}) \times 0.059 + (X_6 \times \mathbf{06.4}) \times 0.022] + A + B$$

**R** Additional refrigerant to be charged [in kg and rounded off to 1 decimal place]

**X<sub>1...6</sub>** Total length [m] of liquid piping size at Øa

**A, B** Parameters A and B (see tables below)

##### • Parameter A:

Piping length <sup>(a)</sup>	CR <sup>(b)</sup>	A <sup>(c)</sup>	
		8 HP	10~14 HP
≤30 m	105%<CR≤130%	0.5 kg	
>30 m	105%<CR≤130%	1.2 kg	1.5 kg

<sup>(a)</sup> Piping length is considered the distance from the outdoor unit to the farthest indoor unit.

<sup>(b)</sup> Total CR = Total indoor unit capacity connection ratio

<sup>(c)</sup> In case of a multi-outdoor-unit system, add the sum of the individual outdoor unit charge factors.

##### • Parameter B:

Parameter B <sup>(a)</sup>	
8 HP, 10 HP, 12 HP	14 HP
2.0 kg	3.8 kg

<sup>(a)</sup> In case of a multi-outdoor-unit system, add the sum of the individual outdoor unit charge factors.

**Metric piping.** When using metric piping, replace the weight factors in the formula by the ones from the following table:

Inch piping		Metric piping	
Piping	Weight factor	Piping	Weight factor
Ø6.4 mm	0.022	Ø6 mm	0.018
Ø9.5 mm	0.059	Ø10 mm	0.065
Ø12.7 mm	0.12	Ø12 mm	0.097
Ø15.9 mm	0.18	Ø15 mm	0.16
		Ø16 mm	0.18
Ø19.1 mm	0.26	Ø18 mm	0.24
Ø22.2 mm	0.37	Ø22 mm	0.35


## Pre-charging refrigerant

### Step 1

Calculate additional refrigerant charge amount: R (kg)

### Step 2

- Open valves C and B to the liquid line
- Execute pre-charging amount: Q (kg)



R=Q

### Step 3a

- Close valves C and B
- Charging is finished
- Fill in the amount on the additional refrigerant charge label
- Go to test run

R<Q

Refrigerant overcharge happened, recover refrigerant to reach R=Q

R>Q

### Step 3b

Close valves C and B

Continued on next page >>


## Charging refrigerant

<< Continuation of previous page

R>Q

### Step 4

- Connect valve A to the refrigerant charge port (d)
- Open all outdoor unit stop valves



### Step 5

Proceed with manual charge

### Step 6

Activate field setting [2-20]=1  
Unit will start manual refrigerant charging operation.

### Step 7

- Open valve A
  - Charge remaining amount of refrigerant P (kg)
- $R=Q+P$

### Step 8

- Close valve A
- Push BS3 to stop manual charging
- Charging is finished
- Fill in the amount on the additional refrigerant charge label
- Go to test run

## 14 Piping installation

### 14.4.5 To charge refrigerant

Follow the steps as described below.

#### Pre-charging refrigerant


- 1 Calculate the additional amount of refrigerant to be added using the formula mentioned in "14.4.3 To determine the additional refrigerant amount" [▶ 22].
- 2 The first 10 kg of additional refrigerant can be pre-charged without outdoor unit operation.

If	Then
The additional refrigerant amount is smaller than 10 kg	Perform steps 2+3.
The additional refrigerant charge is larger than 10 kg	Perform steps 2~8.

- 3 Pre-charging can be done without compressor operation, by connecting the refrigerant bottle to the service ports of the liquid and equalising stop valves (open valve B). Make sure that valve A and all outdoor unit stop valves are closed.

#### NOTICE

During pre-charging, the refrigerant is charged through the liquid line. Close valve A and disconnect the manifold from the gas line.



- a Pressure reducing valve
- b Nitrogen
- c Weighing scales
- d Refrigerant R410A tank (siphon system)
- e Vacuum pump
- f Liquid line stop valve
- g Gas line stop valve
- A Valve A
- B Valve B
- C Valve C

- 4 Do one of the following:


	If	Then
4a	The calculated additional refrigerant amount is reached by above pre-charging procedure	Close valves C and B and disconnect the manifold connection to the liquid line.
4b	The total amount of refrigerant could not be charged by pre-charging	Close valves C and B, disconnect the manifold connection to the liquid line, and perform steps 4~8.

#### INFORMATION

If the total additional refrigerant amount was reached in step 4 (by pre-charging only), record the amount of refrigerant that was added on the additional refrigerant charge label provided with the unit and attach it on the back side of the front panel.

Perform the test procedure as described in "17 Commissioning" [▶ 31].

#### Charging refrigerant



- a Weighing scales
- b Refrigerant R410A tank (siphon system)
- c Vacuum pump
- d Refrigerant charge port
- A Valve A

#### INFORMATION

For a multi outdoor unit system, it is not required to connect all charge ports to a refrigerant tank.

The refrigerant will be charged with  $\pm 22$  kg in 1 hour time at an outdoor temperature of  $30^{\circ}\text{C}$  DB or with  $\pm 6$  kg at an outdoor temperature of  $0^{\circ}\text{C}$  DB.

If you need to speed up in case of a multiple outdoor system, connect the refrigerant tanks to each outdoor unit.

#### NOTICE

- The refrigerant charging port is connected to the piping inside the unit. The unit's internal piping is already factory charged with refrigerant, so be careful when connecting the charge hose.
- After adding the refrigerant, do not forget to close the lid of the refrigerant charging port. The tightening torque for the lid is 11.5 to 13.9 N·m.
- In order to ensure uniform refrigerant distribution, it may take the compressor  $\pm 10$  minutes to start up after the unit has started operation. This is not a malfunction.

- 5 Proceed with the manual charge.

#### INFORMATION

After charging refrigerant:

- Record the additional refrigerant amount on the refrigerant label provided with the unit and attach it to the backside of the front panel.
- Perform the test procedure described in "17 Commissioning" [▶ 31].

### 14.4.6 Step 6: To manually charge refrigerant

#### INFORMATION

The manual refrigerant charge operation will automatically stop within 30 minutes. If charging is not completed after 30 minutes, perform the additional refrigerant charging operation again.

### 14.4.7 Checks after charging refrigerant

- Are all stop valves open?
- Is the amount of refrigerant, that has been added, recorded on the refrigerant charge label?


#### NOTICE

Make sure to open all stop valves after (pre-) charging the refrigerant.

Operating with the stop valves closed will damage the compressor.

### 14.4.8 To fix the fluorinated greenhouse gases label

- 1 Fill in the label as follows:



- a If a multilingual fluorinated greenhouse gases label is delivered with the unit (see accessories), peel off the applicable language and stick it on top of a.
- b Factory refrigerant charge: see unit name plate
- c Additional refrigerant amount charged
- d Total refrigerant charge
- e **Quantity of fluorinated greenhouse gases** of the total refrigerant charge expressed as tonnes CO<sub>2</sub> equivalent.
- f GWP = Global Warming Potential

**NOTICE**

Applicable legislation on **fluorinated greenhouse gases** requires that the refrigerant charge of the unit is indicated both in weight and CO<sub>2</sub> equivalent.

**Formula to calculate the quantity in CO<sub>2</sub> equivalent tonnes:** GWP value of the refrigerant × total refrigerant charge [in kg] / 1000

Use the GWP value mentioned on the refrigerant charge label.

- 2 Fix the label on the inside of the outdoor unit near the gas and liquid stop valves.

## 15 Electrical installation



**DANGER: RISK OF ELECTROCUTION**

**WARNING**

ALWAYS use multicore cable for power supply cables.

**NOTICE**

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

### 15.1 About electrical compliance

**This equipment complies with:**

- **EN/IEC 61000-3-11** provided that the system impedance  $Z_{\text{sys}}$  is less than or equal to  $Z_{\text{max}}$  at the interface point between the user's supply and the public system.
  - EN/IEC 61000-3-11 = European/International Technical Standard setting the limits for voltage changes, voltage fluctuations and flicker in public low-voltage supply systems for equipment with rated current  $\leq 75$  A.
  - It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected **ONLY** to a supply with a system impedance  $Z_{\text{sys}}$  less than or equal to  $Z_{\text{max}}$ .
- **EN/IEC 61000-3-12** provided that the short-circuit power  $S_{\text{sc}}$  is greater than or equal to the minimum  $S_{\text{sc}}$  value at the interface point between the user's supply and the public system.
  - EN/IEC 61000-3-12 = European/International Technical Standard setting the limits for harmonic currents produced by equipment connected to public low-voltage systems with input current  $> 16$  A and  $\leq 75$  A per phase.
  - It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected **ONLY** to a supply with a short-circuit power  $S_{\text{sc}}$  greater than or equal to the minimum  $S_{\text{sc}}$  value.

Model	$Z_{\text{max}}(\Omega)$	Minimum $S_{\text{sc}}$ value (kVA)
RXMLQ8 + RXYLQ10~14	—	5638.32

**INFORMATION**

Multi units are standard combinations.

### 15.2 Safety device requirements

The power supply must be protected with the required safety devices, i.e. a main switch, a slow blow fuse on each phase and an earth leakage protector in accordance with the applicable legislation.

#### For standard combinations

Selection and sizing of the wiring should be done in accordance with the applicable legislation based on the information mentioned in the table below.

Model	Minimum circuit ampacity	Recommended fuses
RXMLQ8	16.1 A	20 A
RXYLQ10	22.0 A	25 A
RXYLQ12	24.0 A	32 A
RXYLQ14	27.0 A	32 A

For all models:

- Phase and frequency: 3N~ 50 Hz
- Voltage: 380~415 V
- Transmission line section: 0.75~1.25 mm<sup>2</sup>, maximum length is 1000 m. If the total interconnection wiring exceeds these limits, it may result in communication error.

#### For non-standard combinations

Calculate the recommended fuse capacity.

Formula	Calculate, by adding the minimum circuit amps of each used unit (according to the table above), multiply the result by 1.1 and select the next higher recommended fuse capacity.
Example	<p>Combining the RXYLQ18 by using the RXMLQ8 and the RXYLQ10.</p> <ul style="list-style-type: none"> <li>• Minimum circuit ampacity of the RXMLQ8=16.1 A</li> <li>• Minimum circuit ampacity of the RXYLQ10=22.0 A</li> </ul> <p>Accordingly, the minimum circuit ampacity of the RXYLQ18=16.1 A+22.0 A=38.1 A</p> <p>Multiply the above result by 1.1: (38.1 A×1.1)= 41.91 A, so the recommended fuse capacity would be <b>45 A</b>.</p>

**NOTICE**

When using residual current operated circuit breakers, be sure to use a high-speed type 300 mA rated residual operating current.

### 15.3 Field wiring: Overview

Field wiring consists of:


- power supply (including earth),
- Interconnection wiring between communication box and outdoor unit,
- RS-485 interconnection wiring between communication box and monitoring system.

**Example:**

**INFORMATION**



The following figure is an example and may NOT completely match your system layout.

## 15 Electrical installation



### 15.4 To route and fix the interconnection wiring

Interconnection wiring can be routed through the front side only. Fix it to the upper mounting hole.



Fix to the indicated plastic brackets using field supplied clamping material.


- a Wiring between the units (indoor-outdoor) (F1/F2 left)
- b Internal interconnection wiring (Q1/Q2)
- c Plastic bracket
- d Field supplied clamps

### 15.5 To connect the interconnection wiring


The wiring from the indoor units must be connected to the F1/F2 (In-Out) terminals on the PCB in the outdoor unit.

Indoor-outdoor connection requirements	
Voltage	220~240 V
Frequency	50 Hz
Wire size	Only use harmonised wiring providing double insulation and suitable for the applicable voltage
	2 core cable
	0.75 to 1.25 mm <sup>2</sup>

#### In case of single outdoor unit installation



#### In case of multi outdoor unit installation



- The interconnecting wiring between the outdoor units in the same piping system must be connected to the Q1/Q2 (Out Multi) terminals. Connecting the wires to the F1/F2 terminals results in system malfunction.
- The wiring for the other systems must be connected to the F1/F2 (Out-Out) terminals of the PCB in the outdoor unit to which the interconnecting wiring for the indoor units is connected.
- The base unit is the outdoor unit to which the interconnecting wiring for the indoor units is connected.


Tightening torque for the interconnection wiring terminal screws:



Screw size	Tightening torque [N·m]
M3.5 (A1P)	0.8~0.96

## 15.6 To finish the interconnection wiring

After installing the interconnection wiring, wrap it along with the onsite refrigerant piping using finishing tape, as shown in the illustration below.




## 15.7 To route and fix the power supply



### NOTICE


When routing earth wires, secure clearance of 25 mm or more away from compressor lead wires. Failure to observe this instruction properly may adversely affect correct operation of other units connected to the same earth.

The power supply wiring can be routed from the front and left side. Fix it to the lower mounting hole.



## 15.8 To connect the power supply

The power supply MUST be clamped to the bracket using field supplied clamp material to prevent external force being applied to the terminal. The green and yellow striped wire MUST be used for earthing only.




### Multiple outdoor units

To connect the power supply for multiple outdoor units to each other, ring tongues have to be used. No bare cable can be used.

In that case, the ring washer that is installed by default should be removed.

Attach both cables to the power supply terminal as indicated below:



## 15.9 To check the insulation resistance of the compressor



### NOTICE

If, after installation, refrigerant accumulates in the compressor, the insulation resistance over the poles can drop, but if it is at least 1 MΩ, then the unit will not break down.

- Use a 500 V mega-tester when measuring insulation.
- Do NOT use a mega-tester for low voltage circuits.

### 1 Measure the insulation resistance over the poles.

If	Then
≥ 1 MΩ	Insulation resistance is OK. This procedure is finished.
< 1 MΩ	Insulation resistance is not OK. Go to the next step.

### 2 Turn ON the power and leave it on for 6 hours.

**Result:** The compressor will heat up and evaporate any refrigerant in the compressor.

### 3 Measure the insulation resistance again.

## 16 Configuration



### DANGER: RISK OF ELECTROCUTION



### INFORMATION

It is important that all information in this chapter is read sequentially by the installer and that the system is configured as applicable.

16 Configuration

16.1 Making field settings

16.1.1 About making field settings

To continue the configuration of the VRV IV heat pump system, it is required to give some input to the PCB of the unit. This chapter will describe how manual input is possible by operating the push buttons/DIP switches on the PCB and reading the feedback from the 7-segment displays.

Making settings is done via the master outdoor unit.

Next to making field settings it is also possible to confirm the current operation parameters of the unit.

Push buttons and DIP switches

Item	Description
Push buttons	By operating the push buttons it is possible to: <ul style="list-style-type: none"><li>Perform special actions (automatic refrigerant charge, testrun, etc).</li><li>Perform field settings (demand operation, low noise, etc).</li></ul>
DIP switches	By operating the DIP switches it is possible to: <ul style="list-style-type: none"><li>DS1 (1): COOL/HEAT selector (refer to the manual of the cool/heat selector switch). OFF=not installed=factory setting</li><li>DS1 (2~4): NOT USED. DO NOT CHANGE THE FACTORY SETTING.</li><li>DS2 (1~4): NOT USED. DO NOT CHANGE THE FACTORY SETTING.</li></ul>

See also:

- "16.1.2 Field setting components" ▶ 28]
- "16.1.3 To access the field setting components" ▶ 28]

PC configurator

For VRV IV heat pump system it is alternatively possible to make several commissioning field settings through a personal computer interface (for this, option EKPCCAB\* is required). The installer can prepare the configuration (off-site) on PC and afterwards upload the configuration to the system.

Mode 1 and 2


Mode	Description
Mode 1 (monitoring settings)	Mode 1 can be used to monitor the current situation of the outdoor unit. Some field setting contents can be monitored as well.
Mode 2 (field settings)	<p>Mode 2 is used to change the field settings of the system. Consulting the current field setting value and changing the current field setting value is possible.</p> <p>In general, normal operation can be resumed without special intervention after changing field settings.</p> <p>Some field settings are used for special operation (e.g., one time operation, recovery/ vacuuming setting, manual adding refrigerant setting, etc.). In such a case, it is required to abort the special operation before normal operation can restart. It will be indicated in below explanations.</p>

See also:

- "16.1.4 To access mode 1 or 2" ▶ 29]
- "16.1.5 To use mode 1" ▶ 29]
- "16.1.6 To use mode 2" ▶ 29]
- "16.1.7 Mode 1: monitoring settings" ▶ 29]
- "16.1.8 Mode 2: field settings" ▶ 30]

16.1.2 Field setting components


Location of the 7-segment displays, buttons and DIP switches:




16.1.3 To access the field setting components

It is not required to open the complete switch box to access the push buttons on the PCB and read out the 7-segment display(s).

To access you can remove the front inspection cover of the front plate (see figure). Now you can open the inspection cover of the switch box front plate (see figure). You can see the three push buttons and the three 7-segment displays and DIP switches.



Operate the switches and push buttons with an insulated stick (such as a closed ball-point pen) to avoid touching of live parts.



Make sure to re-attach the inspection cover into the switch box cover and to close the front plate's inspection cover after the job is finished. During operation of the unit the front plate of the unit should be attached. Settings are still possible to be made through the inspection opening.



NOTICE

Make sure that all outside panels, except for the service cover on the switch box, are closed while working.  
Close the lid of the switch box firmly before turning on the power.

### 16.1.4 To access mode 1 or 2

#### Initialisation: default situation



#### NOTICE

Turn ON the power 6 hours before operation in order to have power running to the crankcase heater and to protect the compressor.

Turn on the power supply of the outdoor unit and all indoor units. When the communication between indoor units and outdoor unit(s) is established and normal, the 7-segment display indication state will be as below (default situation when shipped from factory).

Stage	Display
When turning on the power supply: blinking as indicated. First checks on power supply are executed (8~10 min).	
When no trouble occurs: lighted as indicated (1~2 min).	
Ready for operation: blank display indication as indicated.	

Off  
 Blinking  
 On

In case of malfunction, the malfunction code is displayed on the indoor unit user interface and the outdoor unit 7-segment display. Solve the malfunction code accordingly. The communication wiring should be checked at first.

#### Access

BS1 is used to switch between the default situation, mode 1 and mode 2.

Access	Action
Default situation	
Mode 1	<ul style="list-style-type: none"> <li>Push BS1 one time.</li> </ul> 7-segment display indication changes to: <ul style="list-style-type: none"> <li>Push BS1 one more time to return to the default situation.</li> </ul>
Mode 2	<ul style="list-style-type: none"> <li>Push BS1 for at least five seconds.</li> </ul> 7-segment display indication changes to: <ul style="list-style-type: none"> <li>Push BS1 one more time (short) to return to the default situation.</li> </ul>



#### INFORMATION

If you get confused in the middle of the process, push BS1 to return to the default situation (no indication on 7-segment displays: blank, see "16.1.4 To access mode 1 or 2" ▶ 29).

### 16.1.5 To use mode 1

Mode 1 is used to set basic settings and to monitor the status of the unit.

What	How
Changing and accessing the setting in mode 1	1 Push BS1 one time to select mode 1. 2 Push BS2 to select the required setting. 3 Push BS3 one time to access the selected setting's value.

What	How
To quit and return to the initial status	Push BS1.

### 16.1.6 To use mode 2

The master unit should be used to input field settings in mode 2.

Mode 2 is used to set field settings of the outdoor unit and system.

What	How
Changing and accessing the setting in mode 2	<ul style="list-style-type: none"> <li>Push BS1 for more than five seconds to select mode 2.</li> <li>Push BS2 to select the required setting.</li> <li>Push BS3 one time to access the selected setting's value.</li> </ul>
To quit and return to the initial status	Push BS1.
Changing the value of the selected setting in mode 2	<ul style="list-style-type: none"> <li>Push BS1 for more than five seconds to select mode 2.</li> <li>Push BS2 to select the required setting.</li> <li>Push BS3 one time to access the selected setting's value.</li> <li>Push BS2 to select the required value of the selected setting.</li> <li>Push BS3 one time to validate the change.</li> <li>Push BS3 again to start operation with the chosen value.</li> </ul>

### 16.1.7 Mode 1: monitoring settings

#### [1-0]

Shows whether the unit you check is a master, slave 1 or slave 2 unit.

The master unit should be used to input field settings in mode 2.

[1-0]	Description
No indication	Undefined situation.
0	Outdoor unit is master unit.
1	Outdoor unit is slave 1 unit.
2	Outdoor unit is slave 2 unit.

#### [1-1]

Shows the status of low noise operation.

[1-1]	Description
0	Unit is currently not operating under low noise restrictions.
1	Unit is currently operating under low noise restrictions.

#### [1-2]

Shows the status of power consumption limitation operation.

[1-2]	Description
0	Unit is currently not operating under power consumption limitations.
1	Unit is currently operating under power consumption limitation.

#### [1-5] [1-6]

Code	Shows ...
[1-5]	The current T <sub>e</sub> target parameter position

## 16 Configuration

Code	Shows ...
[1-6]	The current T <sub>c</sub> target parameter position

### [1-10]

Shows the total number of connected indoor units.

### [1-13]

Shows the total number of connected outdoor units (in case of multiple outdoor system).

### [1-17] [1-18] [1-19]

Code	Shows ...
[1-17]	The latest malfunction code
[1-18]	The 2nd last malfunction code
[1-19]	The 3rd last malfunction code

### [1-38] [1-39]

Code	Shows ...
[1-38]	The number of RA DX indoor units connected to the system.
[1-39]	The number of Hydrobox (HXY080/125) indoor units connected to the system.

### [1-40] [1-41]

Code	Shows ...
[1-40]	The current cooling comfort setting
[1-41]	The current heating comfort setting

## 16.1.8 Mode 2: field settings

### [2-0]

Cool/Heat selection setting.

[2-0]	Description
0 (default)	Each individual outdoor unit can select Cool/Heat operation (by Cool/Heat selector if installed), or by defining master indoor user interface (see setting [2-83] and the operation manual).
1	Master unit decides Cool/Heat operation when outdoor units are connected in multiple system combination <sup>(a)</sup> .
2	Slave unit for Cool/Heat operation when outdoor units are connected in multiple system combination <sup>(a)</sup> .

<sup>(a)</sup> It is necessary to use the optional external control adaptor for outdoor unit (DTA104A61/62). See the instruction delivered with the adaptor for further details.

### [2-4]

Cooling/heating test run setting.

For settings 1 and 2, in case room temperature is below 25°C and ambient temperature is below 15°C, a part of the check operation changes to heating operation. The difference between setting 1 and 2 is that setting 2 has additional heating operation to warm up the room (maximum 30 minutes), before cooling check operation.

[2-4]	Description
0 (default)	Cooling check operation.
1	Heating and cooling check operation.
2	Heating and cooling check operation.

### [2-8]

T<sub>c</sub> target temperature during cooling operation.

[2-8]	T <sub>c</sub> target [°C]
0 (default)	Auto

[2-8]	T <sub>c</sub> target [°C]
2	6
3	7
4	8
5	9
6	10
7	11

### [2-9]

T<sub>c</sub> target temperature during heating operation.

[2-9]	T <sub>c</sub> target (°C)
0 (default)	Auto
1	41
3	43
6	46

### [2-20]

Manual additional refrigerant charge.

[2-20]	Description
0 (default)	Deactivated.
1	Activated.  To stop the manual additional refrigerant charge operation (when the required additional refrigerant amount is charged), push BS3. If this function was not aborted by pushing BS3, the unit will stop its operation after 30 minutes. If 30 minutes was not sufficient to add the needed refrigerant amount, the function can be reactivated by changing the field setting again.

### [2-35]

Height difference setting.

[2-35]	Description
0	In case the outdoor unit is installed in the lowest position (indoor units are installed on a higher position than outdoor units) and the height difference between the highest indoor unit and the outdoor unit exceeds 40 m, the setting [2-35] should be changed to 0.
1 (default)	—

### [2-49]

Height difference setting.


[2-49]	Description
0 (default)	—
1	In case the outdoor unit is installed in the highest position (indoor units are installed on a lower position than outdoor units) and the height difference between the lowest indoor unit and the outdoor unit exceeds 50 m, the setting [2-49] has to be changed to 1.

### [2-83]

Master user interface allocation in case VRV DX indoor units and RA DX indoor units are used at the same time.

[2-83]	Description
0	VRV DX indoor unit has mode selection right.
1 (default)	RA DX indoor unit has mode selection right setting.

### 16.1.9 To connect the PC configurator to the outdoor unit



## 17 Commissioning



### NOTICE

**General commissioning checklist.** Next to the commissioning instructions in this chapter, a general commissioning checklist is also available on the Daikin Business Portal (authentication required).

The general commissioning checklist is complementary to the instructions in this chapter and can be used as a guideline and reporting template during commissioning and hand-over to the user.

### 17.1 Precautions when commissioning



### CAUTION

**Do NOT perform the test operation while working on the indoor unit(s).**

When performing the test operation, NOT ONLY the outdoor unit, but the connected indoor unit will operate as well. Working on an indoor unit while performing a test operation is dangerous.



### NOTICE

Turn ON the power 6 hours before operation in order to have power running to the crankcase heater and to protect the compressor.



### NOTICE

Test run is possible for ambient temperatures between -10°C DB and 43°C DB and indoor temperatures between 10°C DB and 32°C DB.

During test operation, the outdoor unit and the indoor units will start up. Make sure that the preparations of all indoor units are finished (field piping, electrical wiring, air purge, ...). See installation manual of the indoor units for details.

### 17.2 Checklist before commissioning

- 1 After the installation of the unit, check the items listed below.
- 2 Close the unit.
- 3 Power up the unit.




You have read the complete installation and operation instructions described in the **installer and user reference guide**.

<input type="checkbox"/>	<b>Installation</b> Check that the unit is properly installed, to avoid abnormal noises and vibrations when starting up the unit.
<input type="checkbox"/>	<b>Transportation stay</b> Check that the outdoor unit's transportation stay is removed.
<input type="checkbox"/>	<b>Field wiring</b> Check that the field wiring has been carried out according to the instructions described in the chapter " <a href="#">15 Electrical installation</a> " [p 25], according to the wiring diagrams and according to the applicable national wiring regulation.
<input type="checkbox"/>	<b>Power supply voltage</b> Check the power supply voltage on the local supply panel. The voltage <b>MUST</b> correspond to the voltage on the nameplate of the unit.
<input type="checkbox"/>	<b>Earth wiring</b> Be sure that the earth wires have been connected properly and that the earth terminals are tightened.
<input type="checkbox"/>	<b>Insulation test of the main power circuit</b> Using a megatester for 500 V, check that the insulation resistance of 2 MΩ or more is attained by applying a voltage of 500 V DC between power terminals and earth. NEVER use the megatester for the interconnection wiring.
<input type="checkbox"/>	<b>Fuses, circuit breakers, or protection devices</b> Check that the fuses, circuit breakers, or the locally installed protection devices are of the size and type specified in the chapter " <a href="#">15.2 Safety device requirements</a> " [p 25]. Be sure that neither a fuse nor a protection device has been bypassed.
<input type="checkbox"/>	<b>Internal wiring</b> Visually check the switch box and the inside of the unit for loose connections or damaged electrical components.
<input type="checkbox"/>	<b>Pipe size and pipe insulation</b> Be sure that correct pipe sizes are installed and that the insulation work is properly executed.
<input type="checkbox"/>	<b>Stop valves</b> Be sure that the stop valves are open on both liquid and gas side.
<input type="checkbox"/>	<b>Damaged equipment</b> Check the inside of the unit for damaged components or squeezed pipes.
<input type="checkbox"/>	<b>Refrigerant leak</b> Check the inside of the unit on refrigerant leakage. If there is a refrigerant leak, try to repair the leak. If the repair is unsuccessful, call your local dealer. Do not touch any refrigerant which has leaked out from refrigerant piping connections. This may result in frostbite.
<input type="checkbox"/>	<b>Oil leak</b> Check the compressor for oil leakage. If there is an oil leak, try to repair the leak. If the repairing is unsuccessful, call your local dealer.
<input type="checkbox"/>	<b>Air inlet/outlet</b> Check that the air inlet and outlet of the unit is NOT obstructed by paper sheets, cardboard, or any other material.
<input type="checkbox"/>	<b>Additional refrigerant charge</b> The amount of refrigerant to be added to the unit shall be written on the included "Added refrigerant" plate and attached to the rear side of the front cover.



## 18 Hand-over to the user

	<b>Installation date and field setting</b> Be sure to keep record of the installation date on the sticker on the rear of the upper front panel according to EN60335-2-40 and keep record of the contents of the field setting(s).
---	--

### 17.3 About the system test run



#### NOTICE

Make sure to carry out the test run after the first installation. Otherwise, the malfunction code **U3** will be displayed on the user interface and normal operation or individual indoor unit test run cannot be carried out.

The procedure below describes the test operation of the complete system. This operation checks and judges following items:

- Check for incorrect wiring (communication check with indoor unit(s)).
- Check of the stop valves opening.
- Judgement of piping length.

In case Hydrobox units or RA DX indoor units are present in the system, the pipe length check will not be performed.

- Abnormalities on indoor units cannot be checked for each unit separately. After the test operation is finished, check the indoor units one by one by performing a normal operation using the user interface. Refer to the indoor unit installation manual for more details (e.g., Hydrobox) concerning the individual test run.



#### INFORMATION

- It may take 10 minutes to achieve a uniform refrigerant state before the compressor starts.
- During the test operation, the refrigerant running sound or the magnetic sound of a solenoid valve may become loud and the display indication may change. These are not malfunctions.

### 17.4 To perform a test run

- 1 Make sure all field settings you want are set; see ["16.1 Making field settings"](#) [p. 28].
- 2 Turn ON the power to the outdoor unit and the connected indoor unit(s).



#### NOTICE

Turn ON the power 6 hours before operation in order to have power running to the crankcase heater and to protect the compressor.

- 3 Make sure the default (idle) situation is existing; see ["16.1.4 To access mode 1 or 2"](#) [p. 29]. Push BS2 for 5 seconds or more. The unit will start test operation.

**Result:** The test operation is automatically carried out, the outdoor unit display will indicate "**LO**" and the indication "Test operation" and "Under centralised control" will display on the user interface of the indoor unit(s).

Steps during the automatic system test run procedure:

In case:

- **Setting [2-4]=0**
- **OR room temperature  $\geq 25^{\circ}\text{C}$ :**

Step	Description
LO 1	Control before start up (pressure equalisation)
LO 2	Cooling start up control
LO 3	Cooling stable condition
LO 4	Communication check
LO 5	Stop valve check

Step	Description
LO 6	Pipe length check
LO 7	Refrigerant amount check (NOT in case of Hydrobox, RA or AHU connection)
LO 10	Unit stop

In case:

- **Setting [2-4]=1 or 2**
- **AND room temperature  $< 25^{\circ}\text{C}$ :**

Step	Description
LO 1	Control before start up (pressure equalisation)
LO 2	Heating start up control
LO 3	Communication check + Stop valve check
LO 4	Pre-heating operation (ONLY if setting [2-4]=2) + Heating pump down control
LO 5	Cooling start up control
LO 10	Unit stop



#### INFORMATION

During the test operation, it is not possible to stop the unit operation from a user interface. To abort the operation, press BS3. The unit will stop after  $\pm 30$  seconds.

- 4 Check the test operation results on the outdoor unit 7-segment display.

Completion	Description
Normal completion	No indication on the 7-segment display (idle).
Abnormal completion	Indication of malfunction code on the 7-segment display.  Refer to <a href="#">"17.5 Correcting after abnormal completion of the test run"</a> [p. 32] to take actions for correcting the abnormality. When the test operation is fully completed, normal operation will be possible after 5 minutes.

### 17.5 Correcting after abnormal completion of the test run

The test operation is only completed if there is no malfunction code displayed on the user interface or outdoor unit 7-segment display. In case of a displayed malfunction code, perform correcting actions as explained in the malfunction code table. Carry out the test operation again and confirm that the abnormality is properly corrected.



#### INFORMATION

Refer to the installation manual of the indoor unit for detailed malfunction codes related to indoor units.

## 18 Hand-over to the user

Once the test run is finished and the unit operates properly, make sure the following is clear for the user:

- Make sure that the user has the printed documentation and ask him/her to keep it for future reference. Inform the user that he/she can find the complete documentation at the URL mentioned earlier in this manual.
- Explain to the user how to properly operate the system and what to do in case of problems.
- Show the user what to do for the maintenance of the unit.



## 19 Troubleshooting

### 19.1 Solving problems based on error codes

In case of a displayed malfunction code, perform correcting actions as explained in the malfunction code table.

After correcting the abnormality, press BS3 to reset the malfunction code and retry operation.

The malfunction code which is displayed on the outdoor unit will indicate a main malfunction code and a sub code. The sub code indicates more detailed information about the malfunction code. The malfunction code will be displayed intermittent.

Example:

Code	Example
Main code	E3
Sub code	-01

With an interval of 1 second, the display will switch between main code and sub code.



#### INFORMATION

See the service manual for:

- The complete list of error codes
- A more detailed troubleshooting guideline for each error

### 19.2 Error codes: Overview

Main code	Sub code			Cause	Solution
	Master	Slave 1	Slave 2		
E3	-01	-03	-05	High pressure switch was activated (S1PH, S2PH) - A1P (X3A; X4A)	Check stop valve situation or abnormalities in (field) piping or airflow over air cooled coil.
	-02	-04	-06	<ul style="list-style-type: none"> <li>▪ Refrigerant overcharge</li> <li>▪ Stop valve closed</li> </ul>	<ul style="list-style-type: none"> <li>▪ Check refrigerant amount+recharge unit.</li> <li>▪ Open stop valves</li> </ul>
	-13	-14	-15	Stop valve closed (liquid)	Open liquid stop valve.
	-18			<ul style="list-style-type: none"> <li>▪ Refrigerant overcharge</li> <li>▪ Stop valve closed</li> </ul>	<ul style="list-style-type: none"> <li>▪ Check refrigerant amount+recharge unit.</li> <li>▪ Open stop valves.</li> </ul>
E4	-01	-02	-03	Low pressure malfunction: <ul style="list-style-type: none"> <li>▪ Stop valve closed</li> <li>▪ Refrigerant shortage</li> <li>▪ Indoor unit malfunction</li> </ul>	<ul style="list-style-type: none"> <li>▪ Open stop valves.</li> <li>▪ Check refrigerant amount+recharge unit.</li> <li>▪ Check the user interface's display or transmission wiring between the outdoor unit and the indoor unit.</li> </ul>
E9	-01	-05	-08	Electronic expansion valve malfunction (subcool) (Y2E) - A1P (X21A)	Check connection on PCB or actuator.
	-04	-07	-10	Electronic expansion valve malfunction (main) (Y1E) - A1P (X23A)	Check connection on PCB or actuator.
	-03	-06	-09	Electronic expansion valve malfunction (storage vessel) (Y3E) - A1P (X22A)	Check connection on PCB or actuator.
F3	-01	-03	-05	Discharge temperature too high (R21T/R22T): <ul style="list-style-type: none"> <li>▪ Stop valve closed</li> <li>▪ Refrigerant shortage</li> </ul>	<ul style="list-style-type: none"> <li>▪ Open stop valves.</li> <li>▪ Check refrigerant amount+recharge unit.</li> </ul>
	-20	-21	-22	Compressor casing temperature too high (R8T): <ul style="list-style-type: none"> <li>▪ Stop valve closed</li> <li>▪ Refrigerant shortage</li> </ul>	<ul style="list-style-type: none"> <li>▪ Open stop valves.</li> <li>▪ Check refrigerant amount+recharge unit.</li> </ul>
F6	-02			<ul style="list-style-type: none"> <li>▪ Refrigerant overcharge</li> <li>▪ Stop valve closed</li> </ul>	<ul style="list-style-type: none"> <li>▪ Check refrigerant amount+recharge unit.</li> <li>▪ Open stop valves.</li> </ul>
H9	-01	-02	-03	Ambient temperature sensor malfunction (R1T) - A1P (X18A)	Check connection on PCB or actuator.

## 19 Troubleshooting

Main code	Sub code			Cause	Solution
	Master	Slave 1	Slave 2		
J3	- 16	-22	-28	Discharge temperature sensor malfunction (R21T): open circuit - A1P (X29A)	Check connection on PCB or actuator.
	- 17	-23	-29	Discharge temperature sensor malfunction (R21T): short circuit - A1P (X29A)	Check connection on PCB or actuator.
	- 18	-24	-30	Discharge temperature sensor malfunction (R22T): open circuit - A1P (X29A)	Check connection on PCB or actuator.
	- 19	-25	-31	Discharge temperature sensor malfunction (R22T): short circuit - A1P (X29A)	Check connection on PCB or actuator.
	-47	-49	-51	Compressor casing temperature sensor malfunction (R8T): open circuit - A1P (X29A)	Check connection on PCB or actuator.
	-48	-50	-52	Compressor casing temperature sensor malfunction (R8T): short circuit - A1P (X29A)	Check connection on PCB or actuator.
J5	-01	-03	-05	Suction temperature sensor malfunction (R3T) - A1P (X30A)	Check connection on PCB or actuator.
J6	-01	-02	-03	De-icing temperature sensor malfunction (R7T) - A1P (X30A)	Check connection on PCB or actuator.
J7	-06	-07	-08	Liquid temperature sensor (after subcool HE) malfunction (R5T) - A1P (X30A)	Check connection on PCB or actuator.
J8	-01	-02	-03	Liquid temperature sensor (coil) malfunction (R4T) - A1P (X30A)	Check connection on PCB or actuator.
J9	-01	-02	-03	Gas temperature sensor (after subcool HE) malfunction (R6T) - A1P (X30A)	Check connection on PCB or actuator.
JR	-06	-08	-10	High pressure sensor malfunction (S1NPH): open circuit - A1P (X32A)	Check connection on PCB or actuator.
	-07	-09	-11	High pressure sensor malfunction (S1NPH): short circuit - A1P (X32A)	Check connection on PCB or actuator.
JC	-06	-08	-10	Low pressure sensor malfunction (S1NPL): open circuit - A1P (X31A)	Check connection on PCB or actuator.
	-07	-09	-11	Low pressure sensor malfunction (S1NPL): short circuit - A1P (X31A)	Check connection on PCB or actuator.
LC	- 14			Transmission outdoor unit - inverter: INV1 transmission trouble - A1P (X20A, X28A, X40A)	Check connection.
	- 19			Transmission outdoor unit - inverter: FAN1 transmission trouble - A1P (X20A, X28A, X40A)	Check connection.
	-24			Transmission outdoor unit - inverter: FAN2 transmission trouble - A1P (X20A, X28A, X40A)	Check connection.
	-30			Transmission outdoor unit - inverter: INV2 transmission trouble - A1P (X20A, X28A, X40A)	Check connection.
P1	-01	-02	-03	INV1 unbalanced power supply voltage	Check if power supply is within range.
	-07	-08	-09	INV2 unbalanced power supply voltage	Check if power supply is within range.
U1	-01	-05	-07	Reversed power supply phase malfunction	Correct phase order.
	-04	-06	-08	Reversed power supply phase malfunction	Correct phase order.
U2	-01	-08	-11	INV1 voltage power shortage	Check if power supply is within range.
	-02	-09	-12	INV1 power phase loss	Check if power supply is within range.
	-22	-25	-28	INV2 voltage power shortage	Check if power supply is within range.
	-23	-26	-29	INV2 power phase loss	Check if power supply is within range.

Main code	Sub code			Cause	Solution
	Master	Slave 1	Slave 2		
U3		-02		Warning indication: Leak detection or refrigerant amount check not performed (system operation possible)	Execute autocharge function (see manual); unit not ready for leak detection functionality.
		-03		Malfunction code: System test run not yet executed (system operation not possible)	Execute system test run.
U4		-01		Faulty wiring to Q1/Q2 or indoor - outdoor	Check (Q1/Q2) wiring.
		-03		Faulty wiring to Q1/Q2 or indoor - outdoor	Check (Q1/Q2) wiring.
		-04		System test run abnormal ending	Execute test run again.
U7		-01		Warning: faulty wiring to Q1/Q2	Check Q1/Q2 wiring.
		-02		Malfunction code: faulty wiring to Q1/Q2	Check Q1/Q2 wiring.
		-11		<ul style="list-style-type: none"> <li>Too many indoor units are connected to F1/F2 line</li> <li>Bad wiring between outdoor and indoor units</li> </ul>	Check indoor unit amount and total capacity connected.
U9		-01		System mismatch. Wrong type of indoor units combined (R410A, R407C, RA, Hydrobox, etc) Indoor unit malfunction	Check if other indoor units have malfunction and confirm indoor unit mix is allowed.
UR		-03		Connection malfunction over indoor units or type mismatch (R410A, R407C, RA, Hydrobox, etc)	Check if other indoor units have malfunction and confirm indoor unit mix is allowed.
		-18		Connection malfunction over indoor units or type mismatch (R410A, R407C, RA, Hydrobox, etc)	Check if other indoor units have malfunction and confirm indoor unit mix is allowed.
		-31		Wrong unit combination (multi system)	Check if unit types are compatible.
		-49		Wrong unit combination (multi system)	Check if unit types are compatible.
UH		-01		Auto address malfunction (inconsistency)	Check if transmission wired unit amount matches with powered unit amount (by monitor mode) or wait till initialisation is finished.
UF		-01		Auto address malfunction (inconsistency)	Check if transmission wired unit amount matches with powered unit amount (by monitor mode) or wait till initialisation is finished.
		-05		Stop valve closed or wrong (during system test run)	Open stop valves.
<b>Auto charging related</b>					
P2		—		Unusual low pressure on suction line	Close valve A immediately. Push BS1 to reset. Check following items before retrying autocharge procedure: <ul style="list-style-type: none"> <li>Check if the gas side stop valve is opened correctly.</li> <li>Check if the valve of the refrigerant cylinder is opened.</li> <li>Check if the air inlet and outlet of the indoor unit are not obstructed.</li> </ul>
P8		—		Freeze-up prevention indoor unit	Close valve A immediately. Push BS1 to reset. Retry autocharge procedure.
PE		—		Automatic charging nearly finished	Prepare for autocharge stopping.
P9		—		Automatic charging finished	Finish autocharge mode.
<b>Leak detection function related</b>					
E-1		—		Unit is not prepared to execute leak detection operation	Refer to requirements to be able to execute leak detection operation.
E-2		—		Indoor unit is out of temperature range for leak detection operation	Retry when ambient conditions are satisfied.
E-3		—		Outdoor unit is out of temperature range for leak detection operation	Retry when ambient conditions are satisfied.

## 20 Technical data


Main code	Sub code			Cause	Solution
	Master	Slave 1	Slave 2		
E-4	—			Too low pressure was noticed during leak detection operation	Restart leak detection operation.
E-5	—			Indicates an indoor unit which is not compatible with leak detection functionality is installed (e.g., RA DX indoor unit, Hydrobox, ...)	Refer to requirements to be able to execute leak detection operation.

## 20 Technical data

- A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible).
- The **full set** of the latest technical data is available on the Daikin Business Portal (authentication required).


### 20.1 Service space: Outdoor unit

Make sure the space around the unit is adequate for servicing and the minimum space for air inlet and air outlet is available (refer to the figure below and choose one of the possibilities).



Layout	A+B+C+D		A+B
	Possibility 1	Possibility 2	
①	a≥10 mm b≥300 mm c≥10 mm d≥500 mm	a≥50 mm b≥100 mm c≥50 mm d≥500 mm	a≥200 mm b≥300 mm
②	a≥10 mm b≥300 mm c≥10 mm d≥500 mm e≥20 mm	a≥50 mm b≥100 mm c≥50 mm d≥500 mm e≥100 mm	a≥200 mm b≥300 mm e≥400 mm

Layout	A+B+C+D		A+B
	Possibility 1	Possibility 2	
③	a≥10 mm b≥300 mm c≥10 mm d≥500 mm e≥20 mm f≥600 mm	a≥50 mm b≥100 mm c≥50 mm d≥500 mm e≥100 mm f≥500 mm	—
④	a≥10 mm b≥300 mm c≥10 mm d≥500 mm e≥20 mm	a≥50 mm b≥100 mm c≥50 mm d≥500 mm e≥100 mm	—
⑤	a≥10 mm b≥500 mm c≥10 mm d≥500 mm e≥20 mm f≥900 mm	a≥50 mm b≥500 mm c≥50 mm d≥500 mm e≥100 mm f≥600 mm	—



(mm)

ABCD Sides along the installation site with obstacles  
F Front side  
Suction side

- In case of an installation site where sides A+B+C+D have obstacles, the wall heights of sides A+C have no impact on service space dimensions. Refer to the figure above for impact of wall heights of sides B+D on service space dimensions.
- In case of an installation site where only the sides A+B have obstacles, the wall heights have no influence on any indicated service space dimensions.
- The installation space required on these drawings are for full load heating operation without considering possible ice accumulation. If the location of the installation is in a cold climate, then all dimensions above should be >500 mm to avoid accumulation of ice in between the outdoor units.



#### INFORMATION

The service space dimensions in above figure are based on cooling operation at 35°C ambient temperature (standard conditions).




#### INFORMATION

Further specifications can be found in the technical engineering data.

## 20.2 Piping diagram: Outdoor unit

Piping diagram: RXMLQ8 + RXYLQ10~14



- a Compressor (M1C)
- b Heat exchanger
- c Fan
- d Fan motor (M1F, M2F)
- e Accumulator
- f Expansion valve, main (Y1E)
- g Expansion valve, subcool heat exchanger (Y2E)
- h Subcool heat exchanger
- i Oil separator
- j 4-way valve, main (Y1S)
- k Solenoid valve, oil accumulator (Y2S)
- l Solenoid valve, oil1 (Y3S)
- m Solenoid valve, injection (Y4S)
- n Solenoid valve, hot gas (Y5S)
- o Service port, refrigerant charge
- p Stop valve (liquid)
- q Stop valve (gas)
- r Service port

## 20.3 Wiring diagram: Outdoor unit

The wiring diagram is delivered with the unit, located at the inside of the service cover.

### Notes to go through before starting the unit

English	Translation
Notes to go through before starting the unit	Notes to go through before starting the unit
Symbols	Symbols
X1M	Main terminal
-----	Earth wiring
15	Wire number 15
-----	Field wire
	Field cable
→ **/12.2	Connection ** continues on page 12 column 2
①	Several wiring possibilities
-----	Option

English	Translation
-----	Not mounted in switch box
-----	Wiring depending on model
-----	PCB

- 1 Refer to the installation or service manual on how to use BS1~BS3 push buttons, and DS1+DS2 DIP switches.
- 2 Do not operate the unit by short-circuiting protection device S1PH.
- 3 For connection of indoor-outdoor F1-F2 transmission wiring, and outdoor-outdoor F1-F2 transmission wiring, refer to the service manual.

### Position in switch box

English	Translation
Position in switch box	Position in switch box

### Legend

A1P	Main PCB
A2P	Noise filter PCB
A3P	Inverter PCB
A4P	SUB PCB
A8P	Adapter PCB
A9P	* Cool/heat selector PCB
BS* (A1P)	Push buttons (mode, set, return)
C* (A3P)	Capacitor
DS* (A1P)	DIP switch
E1HC	Crankcase heater
F1S (A2P)	Surge arrester
F1U (A4P)	Fuse (T, 3.15 A, 250 V)
F401U (A2P)	Fuse (T, 6.3 A, 250 V)
F402U (A2P)	Fuse (T, 6.3 A, 250 V)
F403U (A2P)	Fuse (T, 6.3 A, 250 V)
F410U (A2P)	Fuse (T, 63 A, 600 V)
F411U (A2P)	Fuse (T, 63 A, 600 V)
F412U (A2P)	Fuse (T, 63 A, 600 V)
F*U (A1P)	Fuse (T, 3.15 A, 250 V)
HAP (A1P)	Running LED (service monitor – green)
K1M (A3P)	Magnetic contactor
K*R (A*P)	Magnetic relay
L*R	Reactor
M1C	Motor (compressor)
M*F	Motor (fan)
PS (A1P)	Power supply
Q1DI	# Earth leakage circuit breaker
Q1RP (A1P)	Phase reversal detect circuit
R* (A3P)	Resistor
R*T	Thermistor
R*V (A2P)	Varistor
S1NPH	High pressure sensor
S1NPL	Low pressure sensor
S1PH	High pressure switch (discharge)
S1S	Air control switch
S2S	Cool/heat switch
S3S	Interlock switch
SEG* (A1P)	7-segment display
T1A	Leakage current detection sensor



## 21 Disposal

---

V1R (A3P)	IGBT power module
V2R (A3P)	Diode module
X66A	Connector (remote switching cool/heat selector)
X*A	PCB connector
X*M	Terminal strip
X*M (A*P)	Terminal strip on PCB
X*Y	Connector
Y*E	Electronic expansion valve
Y*S	Solenoid valve
Z*C	Noise filter (ferrite core)
Z*F	Noise filter
	* Optional
	# Field supply

## 21 Disposal



### NOTICE

Do NOT try to dismantle the system yourself: dismantling of the system, treatment of the refrigerant, oil and other parts MUST comply with applicable legislation. Units MUST be treated at a specialised treatment facility for reuse, recycling and recovery.



ERC



4P543426-1 C 0000000\$

Copyright 2018 Daikin

**DAIKIN EUROPE N.V.**

Zandvoordestraat 300, B-8400 Oostende, Belgium

4P543426-1C 2025.01