


OPERATION MANUAL

IFI System air conditioner



Operation manual VRV System air conditioner

English

Betriebsanweisung VRV System Klimaanlage

Deutsch

Manuel d'utilisation Conditionneur d'air VRV System

Français

Manual de operación Sistema de acondicionador de aire VRV

Español

Manuale d'uso Condizionatore d'aria a sistema VRV

Italiano

Εγχειρίδιο λειτουργίας Κλιματιστικό με σύστημα VRV

Ελληνικά

Pro Contract III

Gebruiksaanwijzing Airconditioner met VRV Systeem

Nederlands

Manual de funcionamento Ar condicionado VRV System

Portugues

Руководство по эксплуатации Кондиционер системы VRV

Русский

Kullanım kılavuzu VRV System Klima

Türkçe

Thank you for purchasing this Daikin air conditioner. Carefully read this operation manual before using the air conditioner. It will tell you how to use the unit properly and help you if any trouble occurs. After reading the manual, keep it in your custody for future reference. See also the operation manual included with the indoor unit for details on the indoor unit. Store the operation manual included with the indoor unit together with this operation manual in a safe place. After receiving the warranty card from the dealer, store it in a safe place.

Vielen Dank für den Kauf einer Klimaanlage von Daikin.
Lesen Sie dieses Betriebshandbuch vor Inbetriebnahme der Klimaanlage sorgfältig durch. Sie erfahren hier, wie die Einheit korrekt genutzt wird, und es ist Ihnen bei Störungen behilflich. Lesen Sie das Handbuch sorgfältig und bewahren Sie es für den späteren Gebrauch sorgfältig auf. Weitere Informationen zu diesem Gerät finden Sie in dem beiliegenden Betriebshandbuch. Bewahren Sie das dem Gerät beiliegende Handbuch an einem sicheren Ort auf. Bewahren Sie die Garantiekarte, die Sie von Ihrem Händler erhalten haben, ebenfalls an einem sicheren Ort auf.

Nous vous remercions d'avoir acheté ce climatiseur Daikin. Lisez soigneusement ce manuel d'utilisation avant d'utiliser le climatiseur. Il vous enseignera à utiliser correctement l'unité et vous aidera en cas de panne. Après lecture du manuel, veuillez le conserver à des fins de consultation ultérieure. Veuillez également vous reporter au manuel de l'unité intérieure pour les détails concernant l'unité intérieure. Conservez le manuel de l'unité intérieure avec le présent manuel dans un endroit sûr. Après réception de la carte de garantie transmise par le revendeur, conservez-la dans un endroit sûr.

Gracias por haber adquirido este acondicionador de aire Daikin. Lea con atención este manual antes de utilizar el artefacto. El manual explica cómo usar la unidad correctamente y lo ayuda en caso de que surjan problemas. Una vez leído el manual, consérvelo en lugar seguro para futuras referencias. Asimismo, si lo desea, puede consultar detalles sobre la unidad interior en el manual de funcionamiento provisto con la misma. Guarde el manual de funcionamiento con la unidad interior y con este manual en un lugar seguro. Cuando reciba la tarjeta de garantía del distribuidor, quárdela en un lugar seguro.

La ringraziamo di aver acquistato questo condizionatore d'aria Daikin. Leggere attentamente questo manuale prima di utilizzare il condizionatore. Contiene le istruzioni per usare correttamente l'unità e per rimediare ad eventuali problemi di funzionamento. Dopo aver letto il manuale, conservatelo per il futuro. Vedere anche i dettagli sull'unità interna contenuti nel manuale d'uso in dotazione all'unità interna. Conservare il manuale d'uso in dotazione all'unità interna in un luogo sicuro insieme al presente manuale d'uso. Dopo aver ricevuto la scheda di garanzia dal vostro rivenditore, conservatela in un luogo sicuro.


Σας ευχαριστούμε που αγοράσατε αυτή την κλιματιστική συσκευή της Daikin. Διαβάστε προσεκτικά αυτό το εγχειρίδιο χρήσης πριν χρησιμοποιήσετε την κλιματιστική συσκευή. Θα σας εξηγήσει πως να χρησιμοποιείτε τη μονάδα σωστά και θα σας βοηθήσει αν παρουσιαστεί κάποιο πρόβλημα. Αφού διαβάσετε αυτό το εγχειρίδιο, φυλάξτε το κοντά σας για μελλοντική αναφορά. Βλέπε επίσης το εγχειρίδιο λειτουργίας που περιλαμβάνεται μαζί με την εσωτερική μονάδα για λεπτομέρειες σχετικά με αυτήν. Φυλάξτε το εγχειρίδιο λειτουργίας που περιλαμβάνεται με την εσωτερική μονάδα μαζί με αυτό το εγχειρίδιο λειτουργίας σε ένα ασφαλές μέρος. Αφού λάβετε την κάρτα εγγύησης από τον αντιπρόσωπο, φυλάξτε την σε ένα ασφαλές μέρος.

Hartelijk dank voor uw keuze voor een Daikin airconditioner. Lees deze gebruiksaanwijzing zorgvuldig door voordat u de airconditioner in gebruik neemt. In de gebruiksaanwijzing kunt u lezen hoe u het apparaat op de juiste manier gebruikt en wat u kunt doen bij storingen. Nadat u de handleiding heeft gelezen, dient u deze te bewaren om hem in toekomst te kunnen raadplegen. Raadpleeg eveneens de bedieningshandleiding van de binnenunit voor nadere details over de binnenunit. Berg de bedieningshandleiding voor de binnenunit samen met deze handleiding op een veilige plek op. Berg de garantiekaart op een veilige plek op, zodra u deze van de dealer heeft ontvangen.


Muito obrigado por ter adquirido este aparelho de ar condicionado Daikin. Antes de utilizar o aparelho, leia atentamente o presente manual de funcionamento. Nele obterá informações sobre o modo de utilizar correctamente o aparelho e ajuda na eventualidade de ocorrência de problemas. Após ler o manual, guarde-o para futura referência. Veja também o manual de operação incluso com a unidade interior para maiores detalhes sobre a unidade interior. Guarde o manual de operação incluso com a unidade interior, juntamente com este manual de operação, em um lugar seguro. Após receber o cartão de garantia do revendedor, guarde-o em um lugar seguro.


Спасибо за покупку данного кондиционера фирмы Daikin. До начала работы с кондиционером внимательно изучите данное руководство по эксплуатации. В нем излагаются правила надлежащего пользования устройством и приводятся рекомендации пользователю по поиску и устранению неисправностей. После внимательного прочтения данного руководства храните его в надежном месте для последующего применения. Подробная информация по комнатному блоку приводится в руководстве по эксплуатации, прилагаемом к комнатному блоку. Храните руководство по эксплуатации, прилагаемое к комнатному блоку, в надежном месте вместе с настоящим руководством по эксплуатации. После получения гарантийного талона от продавца, храните гарантийный талон в надежном месте.

Daikin klimalarını satın aldığınız için teşekkür ederiz. Klimayı kullanmadan önce kullanma kılavuzunu dikkatlice okuyunuz. Bu size üniteyi nasıl kullanmanız gerektiği ve eğer herhangi bir sorun oluşursa yardım konusunda bilgi verecektir. Kullanma kılavuzunu okuduktan sonra, ileride başvurmak için saklayınız. Ayrıca iç mekan ünitesi ile birlikte bulunan iç mekan ünitesinin detaylarına ilişkin kullanım kılavuzunu da okuyunuz. İç mekan ünitesi kullanım kılavuzu ve kullanım kılavuzunu birlikte, güvenli bir yerde saklayınız. Satıcıdan garanti belgesini aldıktan sonra, güvenli bir yerde saklayınız.




1






2





4 5









6.1 6.2












9 10 11





CONTENTS

1. SAFETY PRECAUTIONS	1
2. SPECIFICATIONS	4
3. WHAT TO DO BEFORE OPERATION	4
4. REMOTE CONTROLLER AND COOL/HEAT	Γ
SELECTOR: NAME AND FUNCTION OF	
EACH SWITCH AND DISPLAY	4
5. OPERATION RANGE	5
6. OPERATION PROCEDURE	5
7. OPTIMUM OPERATION	7
8. SEASONAL MAINTENANCE	8
9. FOLLOWING SYMPTOMS ARE NOT AIR	
CONDITIONER TROUBLES	8
10. TROUBLE SHOOTING	. 10

1. SAFETY PRECAUTIONS

To gain full advantage of the air conditioner's functions and to avoid malfunction due to mishandling, we recommend that you read this instruction manual carefully before use.

This air conditioner is classified under "appliances not accessible to the general public".

The precautions described herein are classified as WARNING and CAUTION. They both contain important information regarding safety. Be sure to observe all precautions without fail.

MARNING Failure to follow these instructions properly may result in personal injury or loss of life.

CAUTION Failure to observe these instructions properly may result in property damage or personal injury, which may be serious depending on the circumstances.

After reading, keep this manual in a convenient place so that you can refer to it whenever necessary. If the equipment is transferred to a new user, be sure also to hand over the manual.

-∕N WARNING

Be aware that prolonged, direct exposure to cool or warm air from the air conditioner, or to air that is too cool or too warm can be harmful to your physical condition and health.

When the air conditioner is malfunctioning (giving off a burning odour, etc.) turn off power to the unit and contact your local dealer.

Continued operation under such circumstances may result in a failure, electric shocks or fire hazards.

Consult your local dealer about installation work.

Doing the work yourself may result in water leakage, electric shocks or fire hazards.

Consult your local dealer regarding modification, repair and maintenance of the air conditioner.

Improper workmanship may result in water leakage, electric shocks or fire hazards.

Do not place objects, including rods, your fingers, etc., in the air inlet or outlet.

Injury may result due to contact with the air conditioner's highspeed fan blades.

Never touch the air outlet or the horizontal blades while the swing flap is in operation.

Fingers may become caught or the unit may break down.

Beware of fire in case of refrigerant leakage.

If the air conditioner is not operating correctly, i.e. not generating cool or warm air, refrigerant leakage could be the cause.

Consult your dealer for assistance.

The refrigerant within the air conditioner is safe and normally does not leak.

However, in the event of a leakage, contact with a naked burner, heater or cooker may result in generation of noxious gas.

Do not longer use the air conditioner until a qualified service person confirms that the leakage has been repaired.

Consult your local dealer regarding what to do in case of refrigerant leakage.

When the air conditioner is to be installed in a small room, it is necessary to take proper measures so that the amount of any leaked refrigerant does not exceed the concentration limit in the event of a leakage. Otherwise, this may lead to an accident due to oxygen depletion.

Contact professional personnel about attachment of accessories and be sure to use only accessories specified by the manufacturer.

If a defect results from your own workmanship, it may result in water leaks, electric shock or fire.

Consult your local dealer regarding relocation and reinstallation of the air conditioner. Improper installation work may result in leakage, electric shocks or fire hazards.

Be sure to use fuses with the correct ampere reading.

Do not use improper fuses, copper or other wires as a substitute, as this may result in electric shock, fire, injury or damage to the unit.

Be sure to earth the unit.

Do not earth the unit to a utility pipe, lightning conductor or telephone earth lead. Imperfect earthing may result in electric shocks or fire. A high surge current from lightning or other sources may cause damage to the air conditioner.

Be sure to install an earth leakage breaker. Failure to install an earth leakage breaker may result in electric shocks or fire.

Consult the dealer if the air conditioner submerges owing to a natural disaster, such as a flood or typhoon.

Do not operate the air conditioner in that case, or otherwise a malfunction, electric shock, or fire may result.

Do not start or stop operating the air conditioner with the power supply breaker turned ON or OFF.

Otherwise, fire or water leakage may result. Furthermore, the fan will rotate abruptly if power failure compensation is enabled, which may result in inlury.

Do not use the product in the atmosphere contaminated with oil vapor, such as cooking oil or machine oil vapor.

Oil vapor may cause crack damage, electric shocks, or fire.

Do not use the product in places with excessive oily smoke, such as cooking rooms, or in places with flammable gas, corrosive gas, or metal dust.

Using the product in such places may cause fire or product failures.

Do not use flammable materials (e.g., hairspray or insecticide) near the product.

Do not clean the product with organic solvents such as paint thinner.

The use of organic solvents may cause crack damage to the product, electric shocks, or fire.

Be sure to use a dedicated power supply for the air conditioner.

The use of any other power supply may cause heat generation, fire, or product failures.

-/ CAUTION -

Do not use the air conditioner for purposes other than those for which it is intended.

Do not use the air conditioner for cooling precision instruments, food, plants, animals or works of art as this may adversely affect the performance, quality and/or longevity of the object concerned.

Do not remove the outdoor unit's fan guard.

The guard protects against the unit's high speed fan, which may cause injury.

Do not place objects that are susceptible to moisture directly beneath the indoor or outdoor units.

Under certain conditions, condensation on the main unit or refrigerant pipes, air filter dirt or drain blockage may cause dripping, resulting in fouling or failure of the object concerned.

To avoid oxygen depletion, ensure that the room is adequately ventilated if equipment such as a burner is used together with the air conditioner.

After prolonged use, check the unit stand and its mounts for damage.

If left in a damaged condition, the unit may fall and cause injury.

Do not place flammable sprays or operate spray containers near the unit as this may result in fire.

Before cleaning, be sure to stop unit operation, turn the breaker off or remove the power cord.

Otherwise, an electric shock and injury may result.

To avoid electric shocks, do not operate with wet hands.

Do not place appliances that produce naked flames in places exposed to the air flow from the unit as this may impair combustion of the burner.

Do not place heaters directly below the unit, as resulting heat can cause deformation.

Do not allow a child to mount on the outdoor unit or avoid placing any object on it.

Falling or tumbling may result in injury.

Do not place the controller exposed to direct sunlight.

The LCD display may get discolored, failing to display the data.

Do not wipe the controller operation panel with benzine, thinner, chemical dustcloth, etc.

The panel may get discolored or the coating peeled off. If it is heavily dirty, soak a cloth in water-diluted neutral detergent, squeeze it well and wipe the panel clean. And wipe it with another dry cloth.

Do not block air inlets nor outlets.

Impaired air flow may result in insufficient performance or trouble.

Be sure that children, plants or animals are not exposed directly to airflow from the unit, as adverse effects may ensue.

Do not wash the air conditioner or the remote controller with water, as this may result in electric shocks or fire.

Do not install the air conditioner at any place where there is a danger of flammable gas leakage.

In the event of a gas leakage, build-up of gas near the air conditioner may result in fire hazards.

Do not put flammable containers, such as spray cans, within 1 m from the blow-off mouth.

The containers may explode because the warm air output of the indoor or outdoor unit will affect them.

Arrange the drain hose to ensure smooth drainage.

Imperfect drainage may cause wetting.

The appliance is not intended for use by unattended young children or infirm persons.

Impairment of bodily functions and harm to health may result.

Children should be supervised to ensure that they do not play with the unit or its remote controller.

Accidental operation by a child may result in impairment of bodily functions and harm health.

Do not let children play on or around the outdoor unit.

If they touch the unit carelessly, injury may be caused.

Do not place water containers (flower vases, etc.) on the unit, as this may result in electric shocks or fire.

Consult your dealer regarding cleaning the inside of the air conditioner.

Improper cleaning may cause breakage of plastic parts, water leakage and other damage as well as electric shocks.

To avoid injury, do not touch the air inlet or aluminium fins of the unit.

Never press the button of the remote controller with a hard, pointed object.

The remote controller may be damaged.

Never pull or twist the electric wire of a remote controller.

It may cause the unit to malfunction.

Do not operate the air conditioner when using a room fumigation - type insecticide.

Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.

Do not place objects in direct proximity of the outdoor unit and do not let leaves and other debris accumulate around the unit.

Leaves are a hotbed for small animals which can enter the unit. Once in the unit, such animals can cause malfunctions, smoke or fire when making contact with electrical parts.

Never touch the internal parts of the controller.

Do not remove the front panel. Touching certain internal parts will cause electric shocks and damage to the unit. Please consult your dealer about checking and adjustment of internal parts.

Do not leave the remote controller wherever there is a risk of wetting.

If water gets into the remote controller there is a risk of electrical leakage and damage to electronic components.

Watch your steps at the time of air filter cleaning or inspection.

High-place work is required, to which utmost attention must be paid.

If the scaffold is unstable, you may fall or topple down, thus causing injury.

2. SPECIFICATIONS

[Single unit]

Model		RXYN10AY1
Power supply		
Phase	-	3N~
Frequency	(Hz)	50
Voltage	(V)	380-415
Nominal cooling capacity	(kW)	28.0
Nominal heating capacity	(kW)	31.5
Dimensions H×W×D	(mm)	1680×635×765
Mass	(kg)	330
Refrigerant type	-	R744
Refrigerant charge (*1)	(kg)	7.2
Design pressure		
High pressure side	(bar)	123
	(MPa)	12.3
Low pressure side	(bar)	95
	(MPa)	9.5

3. WHAT TO DO BEFORE OPERATION

This operation manual is for the following system with standard control. Before initiating operation, contact your Daikin dealer for the operation that corresponds to your system type and mark.

If your installation has a customized control system, ask your Daikin dealer for the operation that corresponds to your system.

Outdoor units (Refer to figure 1)

	Cool/Heat selector	Operation modes
Inverter series		
heat pumps RXYN series	□ yes □ no	* * *

Names and functions of parts (Refer to figure 1)

- 1. Outdoor unit
- 2. Indoor unit
- 3. BEV unit
- 4. Remote controller
- 5. Inlet air
- 6. Outlet air
- 7. Cool/Heat selector

(figure 1 shows system with Cool/Heat selector)

4. REMOTE CONTROLLER AND COOL/HEAT SELECTOR: NAME AND FUNCTION OF EACH SWITCH AND DISPLAY (Refer to figure 2 and 3)

1. On/off button

Press the button and the system will start. Press the button again and the system will stop.

2. Operation lamp (red)

The lamp lights up during operation.

3. Display " _____ " (changeover under control)
It is impossible to changeover heat/cool with the remote controller which display this icon.

- 4. Display " ♠ OPTION " (ventilation/air cleaning)
 This display shows that the ventilation unit are in operation. (these are optional accessories)
- 5. Display " [-17] (set temperature)

 This display shows the temperature you have set.
- 6. Display " ❖ " " ❖ " " ★ " " ☀ " (operation mode)

This display shows the current operation mode.

7. Display " Jim " (programmed time)

This display shows the programmed time of the system start or stop.

- 8. Display " TEST " (inspection/test operation)
 When the inspection/test operation button is pressed, the display shows the mode in which the system actually is.
- 9. Display " _____ " (under centralized control)
 When this display shows, the system is under centralized control. (This is not a standard specification.)

10. Display " 🏖 🕹 " (fan speed)

This display shows the fan speed you have selected.

11. Display " (time to clean air filter)

Refer to the operation manual of indoor unit.

12. Display " (defrost/hot start)

Refer to the chapter "Operation procedure - Explanation of heating operation."

13. Timer mode start/stop button

Refer to the chapter "Operation procedure - Programming start and stop of the system with timer."

14. Timer on/off button

Refer to the chapter "Operation procedure - Programming start and stop of the system with timer."

15. Inspection/test operation button

This button is only used by qualified service persons for maintenance purposes.

16. Programming time button

Use this button for setting the programming start and/or stop time.

17. Temperature setting button

Use this button for setting the desired temperature.

18. Filter sign reset button

Refer to the operation manual of indoor unit.

19. Fan speed control button

Press this button to select the fan speed of your preference.

20. Operation mode selector button

Press this button to select the operation mode of your preference.

21. Air flow direction adjust button

This button is not available and the display shows "NOT AVAILABLE" when pressed.

22. Fan only/air conditioning selector switch Set the switch to " or fan only operation or to " (f) " for heating or cooling operation.

23. Cool/heat changeover switch

Set the switch to " * " for cooling operation or to " in for heating operation.

24. Thermistor

It sense the room temperature around the remote controller.

25. These button are used when the ventilation unit are installed (These are optional accessories) Refer to the operation manual of the ventilation unit.

NOTE T

- In contradistinction to actual operating situations, the display on figure 1 shows all possible indications.
- Figure 2 shows the remote controller which is opened the cover.

5. OPERATION RANGE

Use the system in the following temperature and humidity ranges for safe and effective operation.

	COOLING	HEATING
outdoor temperature	−5°~43°CDB	-20°~21°CDB
		–20°~15.5°CWB
indoor temperature	21°~32°CDB	15°~27°CDB
	14°~25°CWB	
indoor humidity	3 ≥	30%

NOTE T

To avoid condensation and water dripping out the unit. If the temperature or the humidity is beyond these conditions, safety devices may work and the air conditioner may not operate.

6. OPERATION PROCEDURE

- · Operation procedure varies according to the combination of outdoor unit and remote controller. Read the chapter "What to do before operation".
- To protect the unit, turn on the main power switch 6 hours before operation.
 - And do not turn off the power supply during the air conditioning season because of smoothly start up.
- If the main power supply is turned off during operation, operation will restart automatically after the power turns back on again.

6-1 COOLING, HEATING AND FAN ONLY **OPERATION**

- The operation mode cannot be changed with the remote controller whose display shows
 - " 国太 " (changeover under control). Change the operation mode with the remote controller whose display does not show " ... ".
- When the display " _____ " (changeover under control) flashes, refer to the chapter "Operation procedure - Setting the master remote controller".
- The fan may keep on running for about 1 minute after the heating operation stops for removing the heat in the indoor unit.
- The air flow rate may be adjusted automatically depending on the room temperature or the fan may stop immediately. This is not a malfunction.
- For machine protection the system may control the air flow rate automatically.
- It may take sometime for finishing to change the air flow rate.

This is normal operation.

FOR SYSTEMS WITHOUT COOL/HEAT SELEC-TOR (Refer to figure 4)

- Press the operation mode selector button several times and select the operation mode of vour choice:
 - " * " Cooling operation
 - " " Heating operation
 - " 🏖 " Fan only operation
- Press the on/off button. The operation lamp lights up and the system starts operation.

FOR SYSTEMS WITH COOL/HEAT SELECTOR (Refer to figure 4 and 6)

- Select operation mode with the Cool/Heat selector as follows:
 - " (*) " * Cooling operation (Refer to figure 6.1)
 - " (p)" " We " Heating operation (Refer to figure 6.2)
 - Fan only operation (Refer to figure 6.3)
- Press the on/off button. (Refer to figure 4) The operation lamp lights up and the system starts operation.

ADJUSTMENT (Refer to figure 4)

For adjustment the desired temperature and fan speed follow the procedure shown below.

Press the temperature setting button and set the desired temperature. **A**



Each time this button is pressed, the temperature setting rises or lowers 1°C.

NOTE T

• Set the temperature within the operation range.

- The temperature setting is impossible for fan only operation.
- Press the fan speed control button and select the fan speed of your preference.

STOPPING THE SYSTEM (Refer to figure 4)

Press the on/off button once again.
The operation lamp goes off and the system stops operation.

NOTE TO

- Do not turn off the power immediately after the unit stops.
- The system need at least 5 minutes for residual operation of drain pump device.
 Turning off the power immediately will cause water leak or trouble.

EXPLANATION OF HEATING OPERATION

- For general heating operation, it may take longer to reach the set temperature than in cooling operation.
 We recommend starting the operation which was used before using timer operation.
- The following operation is performed in order to prevent the heating capacity from dropping or cold air from blowing.

Defrost operation

- In heating operation, freezing of the outdoor unit heat exchanger increases. Heating capability decreases and the system goes into defrost operation.
- The indoor unit fan stops and the remote controller displays " ((**)**)".
- After maximum minutes of defrost operation, the system returns to heating operation again.

Hot start

• In order to prevent cold air from blowing out of an indoor unit at the start of heating operation, the indoor fan is automatically stopped. The display of the remote controller shows " (**)** ".

NOTE TO

- The heating capacity drops as the outside temperature falls. If this happens, use another heating device together with the unit. (When using the appliances which produce open fire together, ventilate a room constantly.)
 - Do not place appliances which produce open fire in places exposed to the air flow from the unit or under the unit.
- It takes some time for the room to warm up from the time the unit is started since the unit uses a hot-air circulatory system to warm the entire room.
- If the hot air rises to the ceiling, leaving the area above the floor cold, we recommend using the circulator (the indoor fan for circulating air). Contact your dealer for details.

 While the outdoor temperature is below -20°C, the compressor may not start if the air conditioner is operated within 1 hour after the outdoor unit is turned on.

6-2 PROGRAM DRY OPERATION

- The function of this operation is to decrease the humidity in your room with a minimum temperature decrease.
- The micro computer automatically determines temperature and fan speed.
- The system does not go into operation if the room temperature is low.
- The microcomputer automatically controls the temperature and fan speed, so these cannot be set using the remote controller.
- This function is not available if the room temperature is 20°C or lower.

FOR SYSTEMS WITHOUT COOL/HEAT SELECTOR (Refer to figure 5)

- Press the operation mode selector button several times and select " " (program dry operation).
- Press the on/off button.

 The operation lamp lights up and the system starts operation.
- Press the on/off button once again.
 The operation lamp goes off and the system stops operation.

NOTE 1

- Do not turn off the power immediately after the unit stops.
- The system need at least 5 minutes for residual operation of drain pump device.
 Turning off the power immediately will cause water leak or trouble.

FOR SYSTEMS WITH COOL/HEAT SELECTOR (Refer to figure 7)

- Select cooling operation mode with the Cool/ Heat selector.
- Press the operation mode selector button several times and select program dry " ".
- Press the on/off button.
 The operation lamp lights up and the system starts operation.
- Press the on/off button once again.
 The operation lamp goes off and the system stops operation.

NOTE *

 Do not turn off the power immediately after the unit stops.

 The system need at least 5 minutes for residual operation of drain pump device.
 Turning off the power immediately will cause water leak or trouble.

6-3 PROGRAMMING START AND STOP OF THE SYSTEM WITH TIMER (Refer to figure 8)

The timer is operated in the following two ways.
 Programming the stop time " ④ ▶ ○ ". The system stops operating after the set time has elapsed.

Programming the start time " (4) > | ". The system starts operating after the set time has elapsed.

- The timer can be programmed for a maximum of 72 hours.
- The start and the stop time can be simultaneously programmed.
- Press the timer mode start/stop button several times and select the mode on the display. The display flashes.
 - For setting the timer stop " ④ ▶ "
 - For setting the timer start "♠ | "
- Press the programming time button and set the time for stopping or starting the system.

Each time this button is pressed, the time advances or goes backward by 1 hour.

Press the timer on/off button.

The timer setting procedure ends. The display "④ • ○" or "④ • |" changes from flashing light to constant light.

NOTE T

- When setting the timer off and on at the same time, repeat the above procedure (from " T to " T) once again.
- After the timer is programmed, the display shows the remaining time.
- Press the timer on/off button once again to cancel programming. The display vanishes.

For example: (Refer to figure 10)

When the timer is programmed to stop the system after 3 hours and start the system after 4 hours, the system will stop after 3 hours and start 1 hour later.

6-4 SETTING THE MASTER REMOTE CONTROLLER (Refer to figure 9)

 When one outdoor unit is connected with several indoor units as shown in figure 12, it is necessary to designate one of the remote controllers as the master remote controller.

- Only the master remote controller can select heating, cooling operation.
- The displays of slave remote controllers show " \[
 \sum_{\text{t}}\square\squar

However, it is possible to changeover to program dry with slave remote controllers if the system is in cooling operation by setting on the master remote controller and to changeover to fan only operation.

How to designate the master remote controller

Press the operation mode selector button of the current master remote controller for 4 seconds.

The display showing " <u>\backstylest</u> " (changeover under control) of all slave remote controllers connected to the same outdoor unit flashes.

Press the operation mode selector button of the controller that you wish to designate as the master remote controller. Then designation is completed. This remote controller is designated as the master remote controller and the display showing " (changeover under control) vanishes.

The displays of other remote controllers show " \[\bar{\Bar} \] " (changeover under control).

6-5 PRECAUTIONS FOR GROUP CON-TROL SYSTEM OR TWO REMOTE CON-TROLLER CONTROL SYSTEM

This system provides two other control systems beside individual control (one remote controller controls one indoor unit) system. Confirm about your system to Daikin dealer.

Group control system

One remote controller controls up to 16 indoor units. All indoor units are equally set.

Two remote controller control system

Two remote controllers control one indoor unit (in case of group control system, one group of indoor units). The unit is individually operated.

NOTE TO

 Contact your Daikin dealer in case of changing the combination or setting of group control and two remote controller control systems.

7. OPTIMUM OPERATION

Observe the following precautions to ensure the system operates properly.

 Adjust the air outlet properly and avoid direct air flow to room inhabitants.

- Adjust the room temperature properly for a comfortable environment. Avoid excessive heating or cooling.
- Prevent direct sunlight from entering a room during cooling operation by using curtains or blinds.
- · Ventilate often.
 - Extended use requires special attention to ventilation.
- Do not keep doors and windows opened. If the doors and windows remain open, air will flow out of your room causing a decrease in the cooling or heating effect.
- Never place objects near the air inlet or the air outlet of the unit. It may cause deterioration in the effect or stop the operation.
- Turn off the main power supply switch to the unit when the unit is not used for longer periods of time. If the switch is on, it uses electricity. Before restarting the unit, turn on the main power supply switch 6 hours before operation to ensure smooth running. (Refer to the chapter "Maintenance" in the indoor unit manual.)
- When the display shows " in time to clean the air filter), ask a qualified service person to clean the filters. (Refer to the chapter "Maintenance" in the indoor unit manual.)
- Keep the indoor unit and remote control at least 1 m away from televisions, radios, stereos, and other similar equipment.
 - Failing to do so may cause static or distorted pictures.
- Do not use other heating devices directly beneath the indoor unit.
 - If you do, they might get deformed by the heat.

8. SEASONAL MAINTENANCE

8-1 AT THE BEGINNING OF THE SEASON

Check

 Are the indoor and outdoor unit intake and outlet vents blocked?

Remove anything that might be blocking them.

Clean the air filter and exterior.

• After cleaning the air filter, be sure to put it back in the same position.

See the operation manual included with the indoor unit for details on how to clean it.

Turn the power on.

• When the power comes on, the characters in the remote controller display appear.

(To protect the unit, turn the power on at least 6 hours before operating it. This makes operation smoother.)

NOTE TO

The compressor may not start if the air conditioner is operated within an hour after the outdoor unit is turned on while the outdoor temperature is below –20°C.

8-2 AT THE END OF THE SEASON

On a clear day, use fan operation for around half a day to thoroughly dry out the interior of the unit.

• Refer to page 5 for details on fan operation.

Turn off the power

- When the power is shut off, the characters in the remote controller display disappear.
- When the power is on, the unit consumes up to several dozen Watts of power.
 Turn off the power to conserve energy.

Clean the air filter and exterior.

• After cleaning the air filter, be sure to put it back in the same position.

See the operation manual included with the indoor unit for details on how to clean it.

9. FOLLOWING SYMPTOMS ARE NOT AIR CONDITIONER TROUBLES

9-1 THE SYSTEM DOES NOT OPERATE

 The air conditioner does not start immediately when restart the operation after stop the operation or change operation mode after set the operation mode.

If the operation lamp lights, the system is in normal condition.

To prevent overloading of the compressor motor, the air conditioner starts 5 minutes after it is turned ON again in case it was turned OFF just before.

 If "Centralized Control" is displayed on the remote controller and pressing the operation button causes the display to blink for a few seconds.

This indicates that the central device is controlling the unit.

The blinking display indicates that the remote control cannot be used.

• The system does not start immediately after the power supply is turned on.

Wait one minute until the micro computer is prepared for operation.

9-2 IT STOPS SOMETIMES

 The remote controller display reads "U4" or "U5" and stops but then restarts after a few minutes.

This is because the remote control is intercepting noise from electrical appliances other than the air conditioner, and this prevents communication between the units, causing them to stop. Operation automatically restarts when the noise goes away.

9-3 COOL/HEAT CANNOT BE CHANGED OVER

• When the display shows " \(\text{\tinx}\tint{\text{\tin\text{\texi\text{\text{\text{\texi}\tex{\text{\text{\texi}\tint{\text{\text{\text{\text{\text{\text{\tex

 When the cool/heat selector switch is installed and the display shows " __\" (changeover under control).

This is because cool/heat changeover is controlled by the cool/heat selector. Ask your Daikin dealer where the remote control switch is installed.

9-4 FAN OPERATION IS POSSIBLE, BUT COOLING AND HEATING DO NOT WORK

• Immediately after the power is turned on.
The micro computer is getting ready to operate.
Wait 10 minutes.

9-5 THE FAN STRENGTH DOES NOT COR-RESPOND TO THE SETTING

 The fan strength does no change even if the fan strength adjustment button in pressed.
 During heating operation, when the room temperature reaches the set temperature, the outdoor unit goes off and the indoor unit changes to whisper fan strength.

This is to prevent cold air blowing directly on occupants of the room.

The fan strength will not change even if the button is changed, when another indoor unit is in heating operation.

9-6 WHITE MIST COMES OUT OF A UNIT

Indoor unit

• When humidity is high during cooling operation. If the interior of an indoor unit is extremely contaminated, the temperature distribution inside a room becomes uneven. It is necessary to clean the interior of the indoor unit. Ask your Daikin dealer for details on cleaning the unit. This operation requires a qualified service person.

 Immediately after the cooling operation stops and if the room temperature and humidity are low

This is because warm refrigerant gas flows back into the indoor unit and generates steam.

Indoor unit, outdoor unit

 When the system is changed over to heating operation after defrost operation.
 Moisture generated by defrost becomes steam and is exhausted.

9-7 NOISE OF AIR CONDITIONERS

Indoor unit

- A continuous low "shah" sound is heard when the system is in cooling operation or at a stop.
 When the drain pump (optional accessories) is in operation, this noise is heard.
- A low "sah", "choro-choro" sound is heard while the indoor unit is stopped.
 When the other indoor unit is in operation, this noise is heard. In order to prevent oil and refrigerant from remaining in the system, a small amount

Outdoor unit

When the tone of operating noise changes.
 This noise is caused by the change of frequency.

Indoor unit, outdoor unit

of refrigerant is kept flowing.

 A continuous low hissing sound is heard when the system is in cooling or defrost operation.

This is the sound of refrigerant gas flowing through both indoor and outdoor units.

 A hissing sound which is heard at the start or immediately after stopping operation or defrost operation.

This is the noise of refrigerant caused by flow stop or flow change.

9-8 DUST COMES OUT OF THE UNIT

 When the unit is used after stopping for a long time.

This is because dust has gotten into the unit.

9-9 THE UNITS CAN GIVE OFF ODOURS

• During operation.

The unit can absorb the smell of rooms, furniture, cigarettes, etc., and then emit it again.

9-10 THE OUTDOOR UNIT FAN DOES NOT SPIN

• During operation.

The speed of the fan is controlled in order to optimize product operation.

9-11 THE DISPLAY SHOWS " AR "

 This is the case immediately after the main power supply switch is turned on.

This means that the remote controller is in normal condition. This continues for one minute.

9-12 THE COMPRESSOR OR FAN IN THE **OUTDOOR UNIT DOES NOT STOP**

• This is to prevent oil and refrigerant from remaining in the compressor. The unit will stop after 5 to 10 minutes.

9-13 THE INSIDE OF AN OUTDOOR UNIT IS WARM EVEN WHEN THE UNIT HAS **STOPPED**

· This is because the crankcase heater is warming the compressor so that the compressor can start smoothly.

9-14 IT STOPS SOMETIMES

• The remote controller display reads "U4" and "U5" and stops but then restarts after a few minutes.

This is because the remote control is intercepting noise from electrical appliances other than the air conditioner, and this prevents communication between the units, causing them to stop. Operation automatically restarts when the noise goes away.

9-15 HOT AIR IS EMITTED EVEN THOUGH THE UNIT IS STOPPED

· Hot air can be felt when the unit is stopped. Several different indoor units are being run on the same system, so if another unit is running, some refrigerant will still flow through the unit.

9-16 DOES NOT COOL VERY WELL

• Program dry operation.

Program dry operation is designed to lower the room temperature as little as possible. Refer to page 6.

10. TROUBLE SHOOTING

If one of the following malfunctions occur, take the measures shown below and contact your Daikin dealer.

-∕!\ WARNING

Stop operation and shut off the power if anything unusual occurs (burning smells, etc.) Leaving the unit running under such circumstances may cause breakage, electrical shock, or fire. Contact your dealer.

- If a safety device such as a fuse, a breaker or an earth leakage breaker frequently actuates; Measure: Do not turn on the main power switch.
- If the ON/OFF switch does not properly work; Measure: Turn off the main power switch.
- · If water leaks from unit; Measure: Stop the operation.
- The operation switch does not work well. Turn off the power.
- If the display " the unit number and the operation lamp flash and the malfunction code appears; (Refer to figure 11)
 - 1. Inspection display
 - 2. Indoor unit number in which a malfunction occurs
 - 3. Operation lamp
 - 4. Malfunction code

Measure: Notify your Daikin dealer and report the malfunction code.

If the system does not properly operate except for the above mentioned cases and none of the above mentioned malfunctions is evident, investigate the system according to the following procedures.


If it is impossible to fix the problem yourself after checking all the above items, contact your dealer.

Let him know the symptoms, system name, and model name (listed on the warranty card).

- 1. If the system does not operate at all;
- Check if there is no power failure. Wait until power is restored. If power failure occurs during operation, the system automatically restarts immediately after the power supply is recovered.
- · Check if no fuse has blown; Turn off the power supply
- · Check if the breaker is blown.

Turn the power on with the breaker switch in the off position.

Do not turn the power on with the breaker switch in the trip position. (Contact your dealer.)



- 2. If the system stops soon after starting the operation;
- · Check if air inlet or outlet of outdoor or indoor unit is not blocked by obstacles.

Remove any obstacle and make it well-ventilated.

- · Check if the remote controller display shows

Refer to the operation manual of the indoor unit. And clean the air filter.

- 3. The system operates but cooling or heating is insufficient:
- Check if air inlet or outlet of outdoor or indoor unit is not blocked by obstacles.

Remove any obstacle and make it well-ventilated.

• Check if the remote controller display shows " a ' (time to clean the air filter);

Refer to the operation manual of the indoor unit. And clean the air filter.

- Check the temperature setting. Refer to "Operation procedure".
- Check the fan speed setting on your remote controller.

Refer to "Operation procedure".

- Check for open doors or windows.
 Shut doors and windows to prevent wind from coming in.
- Check if there are too many occupants in the room during cooling operation.
- Check if the heat source of the room is excessive during cooling operation.
- Check if direct sunlight enters the room during cooling operation.

Use curtains or blinds.

After-sales service and warranty

After-sales service:

—∕!\ WARNING

• Do not modify the unit.

This may cause electric shock or fire.

- Do not disassemble or repair the unit.
 This may cause electric shock or fire.
 Contact your dealer.
- If the refrigerant leaks, keep out of fire.

 Although the refrigerant does not usually leak, if the refrigerant leaks out into a room and comes in contact with the combustible air in the equipment such as fan heater, stove, oil (gas) cooker, etc., it will cause toxic gas to be generated.

 When a refrigerant leakage failure has been repaired, confirm a service person that the leakage point has been corrected
- Do not remove or reinstall the unit by yourself.
 Incorrect installation may cause electrical shock or fire.

Contact your dealer.

- When asking your dealer to repair, inform related staff of the details as follows:
 - Product No. of air conditioner:

surely before restarting operation.

Refer to the warranty card.

Shipping date and installation date:

Refer to the warranty card.

Malfunction:

Inform the staff of the defective details. (Malfunction code being displayed on the remote controller.)

- Name, address, telephone number
- Repair where the warranty term is expired
 Contact your dealer. If necessary to repair, pay
 service is available.
- Minimum storage period of important parts
 Even after a certain type of air conditioner is discontinued, we have the related important parts in
 stock for 9 years at least.

The important parts indicate parts essential to operate the air conditioner.

Recommendations for maintenance and inspection

Since dust collects after using the unit for several years, the performance will be deteriorated to some extent.

Taking apart and cleaning inside require technical expertise, so we recommend entering a maintenance and inspection contract (at a cost) separate from normal maintenance.

Recommended inspection and maintenance cycles

[Note: The maintenance cycle is not the same as the warranty period.]

Table 1 assumes the following usage conditions.

- 1. Normal use without frequent starting and stopping of the machine.
 - (Although it varies with the model, we recommend not starting and stopping the machine more than 6 times/hour for normal use.)
- 2. Operation of the product is assumed to be 10 hours/day, 2500 hours/year.
- Table 1 "Inspection Cycle" and "Maintenance Cycle" Lists

Name of Main Part	Inspection Cycle	Maintenance Cycle [replacements and/ or repairs]
Electric motor (fan, damper, etc.)	- 1 year	20,000 hours
PC boards		25,000 hours
Heat exchanger		5 years
Sensor (thermistor, etc.)		5 years
Remote controller and switches		25,000 hours
Drain pan		8 years
Expansion valve		20,000 hours
Electromagnetic valve		20,000 hours

Note 1

This table indicates main parts.

See the maintenance and inspection contract for details.

Note 2

This maintenance cycle indicates recommended lengths of time until the need arises for maintenance work, in order to ensure the product is operational as long as possible

Use for appropriate maintenance design (budgeting maintenance and inspection fees, etc.)

Depending on the content of the maintenance and inspection contract, the inspection and maintenance cycles may in reality be shorter than those listed here.

Shortening of "maintenance cycle" and "replacement cycle" needs to be considered in the following cases.

- 1. When used in hot, humid locations or locations where temperature and humidity fluctuate greatly.
- When used in locations where power fluctuation (voltage, frequency, wave distortion, etc.) is high. (Cannot be used if it is outside the allowable range.)
- 3. When installed and used in locations where bumps and vibrations are frequent.
- 4. When used in bad locations where dust, salt, harmful gas or oil mist such as sulfurous acid and hydrogen sulfide may be present in the air.
- When used in locations where the machine is started and stopped frequently or operation time is long. (Example: 24 hour air-conditioning)

■ Recommended replacement cycle of wear-out parts

[The cycle is not the same as the warranty period.]

• Table 2 "Replacement Cycle" Lists

Name of Main Part	Inspection Cycle	Replacement Cycle
Air filter		5 years
High efficiency filter (Optional accessory)	1 year	1 year
Fuse		10 years
Crankcase heater		8 years

Note 1

This table indicates main parts.

See the maintenance and inspection contract for details.

Note 2

This maintenance cycle indicates recommended lengths of time until the need arises for maintenance work, in order to ensure the product is operational as long as possible.

Use for appropriate maintenance design (budgeting maintenance and inspection fees, etc.).

Contact your dealer for details.

Note: Breakage due to taking apart or cleaning inside by anyone other than our authorized dealers may not be included in the warranty.

■ Moving and discarding the unit

 Contact your dealer for removing and reinstalling the system air conditioner since they require technical expertise.

■ Where to call

For after-sales service, etc., consult with your dealer.

■ Warranty period:

This product includes a warranty card.
 The warranty card is given to a customer after dealer staff fills out necessary items in the card.
 The customer should check the entered items and store it carefully.

Warranty period: Within one year after

installation.

For further details, refer to

the warranty card.

• If it is necessary to repair the air conditioner within the warranty period, contact your dealer and show your warranty card. If the warranty card is not shown, pay-service repair may be performed even though the warranty period is not expired.

DAIKIN INDUSTRIES, LTD.

DAIKIN EUROPE NV

Head office: Umeda Center Bldg., 2-4-12, Nakazaki-Nishi,

Kita-ku, Osaka, 530-8323 Japan

Tokyo office: JR Shinagawa East Bldg., 2-18-1, Konan, Minato-ku, Tokyo, 108-0075 Japan Zandvoordestraat 300, B-8400 Oostende, Belgium